

Delites

Delites

Model: NL001

NỒI LỬU ĐIỆN
ELECTRIC HOTPOT



3.0L



HƯỚNG DẪN SỬ DỤNG

NỒI LỬU ĐIỆN DELITES NL001

Vui lòng đọc kỹ hướng dẫn trước khi sử dụng sản phẩm để nắm các thông số kỹ thuật và các sử dụng một cách tốt nhất và tránh gây hư hỏng sản phẩm do sử dụng sai cách, gây mất an toàn cho quý khách hàng.

CẢNH BÁO AN TOÀN KHI SỬ DỤNG

- Nồi lẩu điện chỉ kết nối với ổ cắm điện có dây tiếp đất, luôn đảm bảo phích cắm được gắn chặt vào ổ cắm điện. Tuyệt đối không sử dụng chung ổ cắm với các thiết bị khác.
- Không được đặt Nồi lẩu điện trên bề mặt không chắc chắn, ẩm ướt hoặc gần các nguồn nhiệt khác, nó có thể gây nguy hiểm hoặc làm hỏng Nồi lẩu điện.
- Không được cho thêm nước hoặc thực phẩm khác vào khi nồi lẩu đang sôi.
- Đặt sản phẩm cách xa tầm tay trẻ em, không để trẻ nhỏ sử dụng sản phẩm một mình mà không có sự giám sát của người lớn.
- Không được dùng tay chạm trực tiếp vào các bộ phận: lòng nồi, thành nồi và mâm nhiệt khi đang sử dụng Nồi lẩu điện để tránh gây bỏng da.
- Không được đun nóng lòng nồi trên bếp gas hoặc các nguồn nhiệt khác để tránh gây biến dạng lòng nồi, ảnh hưởng đến hiệu quả hoạt động của Nồi lẩu điện.
- Vui lòng không tự ý sửa chữa sản phẩm khi phát hiện sản phẩm bị lỗi mà phải gửi sản phẩm Trung tâm bảo hành được chỉ định để sửa chữa.

BẢO QUẢN VÀ VỆ SINH SẢN PHẨM

- Sau mỗi lần sử dụng, hãy chắc chắn phích cắm đã được rút ra khỏi nguồn điện và chỉ bắt đầu vệ sinh sản phẩm sau khi toàn bộ thiết bị đã nguội hẳn.
- Để làm sạch, tốt nhất nên sử dụng vải mềm nhúng trong chất tẩy rửa trung tính, không sử dụng bàn chải bằng kim loại chà xát bề mặt lòng nồi hoặc dùng dung môi có tính ăn mòn cao để tránh gây hư hỏng, bong tróc lớp chống dính trên bề mặt lòng nồi.
- Không được rửa hoặc nhúng toàn bộ thân nồi, mâm nhiệt vào nước vì có thể gây chập điện hoặc điện giật rất nguy hiểm. Chỉ nên sử dụng khăn ẩm vệ sinh bên ngoài.
- Vệ sinh nắp nồi, lòng nồi bằng vải mềm có những chất tẩy rửa trung tính.
- Khi không sử dụng sản phẩm một thời gian dài thì nên bảo quản sản phẩm nơi thoáng mát, tránh ẩm thấp, vệ sinh sản phẩm sạch sẽ và lau khô.

MÔ TẢ SẢN PHẨM VÀ PHỤ TÙNG

Nồi lẩu điện Delites Model: NL001 được sản xuất bằng cách sử dụng quy trình tiên tiến và các thông số kỹ thuật của sản phẩm đáp ứng yêu cầu tiêu chuẩn quốc gia. Với chất lượng đáng tin cậy và độ bền tốt, sản phẩm là một thiết bị điện gia dụng lý tưởng để sử dụng trong căn bếp của gia đình.

1

TÍNH NĂNG NỔI BẬT

- Chức năng kiểm soát nhiệt độ khi nấu
- Chế độ bảo vệ cầu chì để tránh tình trạng tăng nhiệt độ quá cao trong khi nấu.
- Lòng nồi tráng men chống dính, dễ dàng vệ sinh
- Nắp nồi bằng thủy tinh trong suốt, chịu nhiệt tốt

THÔNG SỐ KỸ THUẬT SẢN PHẨM

Model	Điện áp	Công suất	Dung tích sản phẩm
NL001	220V – 50Hz	1300W	3.0L

HƯỚNG DẪN SỬ DỤNG

- Hãy chắc chắn làm sạch các vết nước và vật lạ từ bề mặt lòng nồi và mâm nhiệt, sau đó đặt lòng nồi vào thân nồi và xoay nhẹ vài lần để đảm bảo nồi trong được đặt chính xác và tiếp xúc tốt với mâm nhiệt. Nếu không việc truyền nhiệt sẽ kém, ảnh hưởng đến sự điều chỉnh tăng nhiệt độ theo cách thông thường.
- Trước khi cắm thiết bị, vui lòng đặt nút nhiệt ở vị trí "OFF". Đảm bảo nguồn điện là 220 V ~ điện AC. Các ổ cắm có thể chịu được dòng điện định mức không dưới 10A và có sẵn dây tiếp đất an toàn. Nếu không, thiết bị không được phép sử dụng.
- Chức năng hấp, nấu súp, nấu lẩu
 - Sau khi cắm thiết bị, đặt nút nhiệt ở vị trí chức năng cần thiết (tại thời điểm này, đèn tín hiệu sẽ bật sáng lên).
 - Sau khi nấu một thời gian, đặt nút nhiệt ở vị trí theo yêu cầu.
- Đặt nút nhiệt ở vị trí "OFF" và rút phích cắm ra

LƯU Ý:

Đối với lần đầu sử dụng sản phẩm cần kiểm tra xem phích cắm có phù hợp với ổ cắm hay không. Phương pháp kiểm tra: đầu tiên cắm phích cắm vào ổ cắm điện, sau khi hoạt động được nửa giờ thì tắt thiết bị và rút phích cắm ra khỏi ổ điện, kiểm tra nhiệt độ của chân phích cắm, nếu chúng quá nóng (khoảng trên 50 độ C), vui lòng thay ổ cắm mới tốt hơn để phòng tránh cháy nổ do tiếp xúc kém

Cảm ơn quý khách hàng đã tin tưởng lựa chọn sản phẩm!

2

IMPORTANT SAFEGUARDS

- Besure to use an earthing switch socket, and the socket must be inserted tightly. Never use a universal socket or have a socket shared with other appliances.
- The inner pot, enclosure and electrothermal disk are very hot when in use or within some time after shutdown. Never touch them with your hand.
- Besure to use the pot specific for the product and do not put other pots on the electro thermal disk of this product for cooking.
- If the power line of the appliance is broken, ask a qualified personnel from the manu facturer to replace it.
- Do not put the electric cooker in a place which is unstable or wet or near other fire or heat sources, or it may damaged.
- Do not put the inner pot ona gas stove or other heat sources, or it may deform and affect operation.
- When the inner pot is not placed in the cooker body, do not pour hot water or other substances into the pot.
- In case any defects are found, do not dismantle the unit by yourself. Send it toa qualified technician from the manufacturer department.
- Do not cook directly on the electrothermal disk so as to prevent from causing failures and electric shocks.
- Do not use metallic or any sharp appliance to scrape the inner pot. Otherwise, the non-stick coating will be damaged.

CLEANING & MAINTENANCE

- After each use, pull out the plug and start cleaning only when the cooker body completely cools down. For cleaning, use soft cloth dipped in neutral detergent. Do not use metal brushes or corrosive solvents to avoid damages to the non-stick layer.
- Do not immerse the electric cooker in water and do not wash the electrothermal disk with water to prevent electric shocks and malfunctions. Wipe off the attached sundries with a slightly damp cloth.
- Clean the lid and enclosure surface with soft cloth dipped in neutral detergent.
- When the cooker is not going to be used for some time, clean and store it after it dries up.

PARTS & DESCRIPTION

Electric Hotpot Delites Model: NL001 is manufactured by using advanced process, and its various performance indexes meet the requirements of national standards. With reliable quality and long endurance, the product is an ideal kitchen electrothermal appliance for use in families.

3

IPERFORMANCE CHARACTERISTICS

- Having temperature control function to control cooking temperature.
- Provided with fuse protector (heat protector) to prevent from usual overheat.
- Non-stick inner pot, easy to wash.
- High-strength high temperature resistant glass cover.

SPECIFICATIONS

Model	Voltage	Power	Capacity
NL001	220V – 50Hz	1300W	3.0L

USING YOUR APPLIANCE

- Be sure to clean water splashes and foreign article from the pot and electrothermal disk surface, then place the inner pot into the cooker body and gently rotate it several times to ensure that the inner pot is correctly placed and has good contact with the electrothermal disk. Otherwise, heat transfer will be poor, affecting the normal tempera-ture rise.
- Before plugging in the unit, please set the thermal button to the "OFF" position. Make sure the power supply is 220V~ AC electricity. The outlet can withstand rated current of no less than 10A and safe earthing is available. Otherwise, the unit is not allowed to be used.
- Steam, Soup, Hot pot
 - After plugging in the unit, set the thermal button to the function position required (at this moment, the heating lamp lights up).
 - After cooking for some time, set the thermal button to a position as required.
- Set the thermal button to the "OFF" position and pull out the plug.

ATTENTION

Where the unit is used for the first time or the socket is frequently used, please regularly check whether the plug can match the socket well; methods for inspection: First, insert the plug into the socket, turn off the unit after it operates for half an hour and then pull out the plug. Check whether the plug pins burn the hand. If they are so hot as to burn the hand (approximately over 50), please make sure to replace the socket with a well contacted socket so as to prevent from burning out the plug or fire due to the overheat-ing caused by poor contact.

Thank you for choosing our product!

4