

Delites

Model: HHB1732

BÌNH ĐUN SIÊU TỐC
Electric Kettle



CHỈ SỬ DỤNG TRONG NHÀ

Hãy lưu giữ và đọc hướng dẫn này thật kỹ trước khi sử dụng.

1.7L



Hướng dẫn an toàn chung

- Trước khi vận hành ấm đun nước này, vui lòng đọc kỹ hướng dẫn sử dụng.
- Hãy giữ hướng dẫn sử dụng, giấy bảo hành, biên lai bán hàng và nếu có thể, giữ cả thùng carton có bao bì bên trong.
- Ấm này được dành riêng cho tư nhân và không dành cho mục đích thương mại
- Tắt ấm và rút phích cắm ra khỏi ổ cắm khi không sử dụng ấm. Khi bạn ngắt kết nối dây nguồn của ấm, hãy nắm và rút phích cắm, không phải dây / cáp.
- Tắt ấm trước khi vệ sinh ấm.
- Để ấm nước xa tầm tay trẻ em. Không để trẻ em gần ấm nước nếu không có sự giám sát.
- Thiết bị này có thể được sử dụng cho trẻ em từ 8 tuổi trở lên nếu chúng được giám sát hoặc hướng dẫn sử dụng thiết bị một cách an toàn và hiểu các mối nguy hiểm liên quan. Việc vệ sinh ấm không được phép thực hiện bởi trẻ em dưới 8 tuổi và không có sự giám sát. Giữ thiết bị và dây nguồn của ấm xa tầm tay trẻ em dưới 8 tuổi. Thiết bị có thể được sử dụng bởi những người bị giảm khả năng thể chất, cảm giác hoặc tinh thần hoặc thiếu kinh nghiệm và kiến thức nếu họ được giám sát hoặc hướng dẫn sử dụng thiết bị một cách an toàn và hiểu các mối nguy hiểm liên quan. Trẻ em không được chơi với thiết bị .
- Kiểm tra bình đun và dây / cáp thường xuyên xem có bị hỏng không. Kiểm tra ấm đun nước có đang hoạt động đúng. Nếu có bất kỳ hư hỏng nào hoặc nếu ấm không hoạt động bình thường, hãy ngừng sử dụng ấm và rút phích cắm ngay lập tức.
- Không tự sửa chữa ấm đun nước, chỉ những người có kỹ thuật và có trình độ liên quan mới có thể sửa chữa ấm đun nước này.
- Giữ ấm và dây / cáp tránh xa nhiệt, ánh sáng mặt trời trực tiếp, nước, hơi ẩm, các cạnh sắc và những thứ tương tự.
- Chỉ sử dụng các phụ kiện gốc, không thay thế bằng các phụ kiện không tương thích.
- Không sử dụng ấm đun nước ngoài trời.
- Để nguồn và mặt ngoài của ấm phải luôn luôn khô ráo.
- Trong mọi trường hợp, không được đặt ấm trong nước hoặc bất kỳ chất lỏng nào, không để ấm tiếp xúc với chất lỏng. Không chạm vào ấm bằng tay ướt hoặc ẩm. Nếu ấm bị ướt, hãy rút phích cắm chính ra khỏi ổ cắm ngay lập tức.
- KHÔNG chạm vào mạch điện của ấm.
- Chỉ sử dụng ấm cho đúng mục đích của nó.
- Ấm chỉ được sử dụng với chân đế được cung cấp.
- Nếu dây cung cấp bị hỏng, nó phải được thay thế bởi nhà sản xuất, trung tâm bảo hành hoặc những người có trình độ tương tự để tránh nguy hiểm.
- Tránh làm đổ nước vào đầu nối trong khi sử dụng.
- Cảnh báo: Nếu ấm quá đầy, nước sôi có thể bị văng ra.

1

Hướng dẫn an toàn đặc biệt cho ấm đun nước

- Mức nước phải nằm trong khoảng giữa 2 vạch MAX. và MIN .
- Tắt ấm trước khi tháo nó ra khỏi đế.
- Luôn đảm bảo rằng nắp được đóng kín.
- Đế và mặt ngoài của ấm không được bị ướt.
- Thân ấm được sử dụng phải phù hợp với đế ấm.

Lần đầu tiên sử dụng ấm đun nước

- Trước khi sử dụng ấm lần đầu tiên, hãy đổ nước vào ấm và đun sôi hai lần mà không cần bất kỳ chất phụ gia nào.
- 1. Đổ nước vào ấm. Đùng quá đầy. Sử dụng chỉ báo mức nước.
- 2. Đặt ấm trên đế.
- 3. Kết nối điện
- Kiểm tra xem điện áp mà bạn định sử dụng có giống với điện áp của ấm không. Thông tin chi tiết có thể được tìm thấy trên nhãn trên đế của ấm.
- Chỉ kết nối ấm với ổ cắm 220-240V 50 / 60Hz được lắp đặt đúng cách.
- 4. Chuyển ấm sang vị trí '1'. Đèn điều khiển trên đèn báo nước cho thấy nước đang được đun sôi.
- 5. Sau khi đun sôi, ấm sẽ tự động tắt.
- Ngắt kết nối ấm từ nguồn điện chính.
- Không mở nắp khi đổ nước ra.
- 6. Thiết bị này được thiết kế để sử dụng trong gia đình và các mục đích tương tự như:
 - khu vực bếp của nhân viên trong các cửa hàng, văn phòng và môi trường làm việc khác;
 - nhà ở trong trang trại;
 - Trong khách sạn, nhà nghỉ ;

Làm sạch

Luôn rút phích cắm ra khỏi nguồn điện trước khi vệ sinh ấm. Bên ngoài của ấm nên được làm sạch, nếu cần thiết, với một miếng vải hơi ẩm mà không có chất phụ gia. Bọt lọc canxi có thể được gỡ bỏ để làm sạch

Nguồn cấp:

220-240V ~ 50 / 60Hz 1850-2200W

2

General Safety Instructions

- Before commissioning this kettle, please read the instruction manual carefully.
- Please keep the instruction manual, guarantee certificate, the sales receipt and if possible, the carton with the inner packaging.
- This kettle is intended exclusively for private and not for commercial use
- Switch off the kettle and remove the plug from the socket when the kettle is not in use. When you disconnect the power cord of the kettle, grasp and pull the plug, not the cord/cable.
- Switch off the kettle before cleaning the kettle.
- Keep the kettle out of the reach of children. Do not leave children unsupervised with the kettle.
- This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children aged less than 8 years. Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.Children shall not play with the appliance.
- Test the kettle and the cord/cable regularly for damage. Check that the kettle and is operating properly. If there is damage of any kind or if the kettle is not operating properly, stop using the kettle and unplug it immediately.
- Do not attempt to repair the kettle yourself, only authorised and qualified personnel may repair this kettle.
- Keep the kettle and cord/cable away from heat, direct sunlight, water, moisture, sharp edges and the like.
- Use only original accessories, do not connect incompatible products.
- Do not use the kettle outdoors.
- The base and exterior of the kettle are not water-resistant, keep it dry at all times.
- Under no circumstances must the kettle be placed in water or any liquid or come in contact with liquid. Do not handle the kettle with wet or moist hands. Should the kettle become wet or moist, remove the main plug from the socket immediately.
- DO NOT touch the contents of the kettle.
- Use the kettle only for its intended purpose.
- The kettle is only to be used with the stand provided.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Avoid water spillage on connector during use.
- Warning:If the kettle is overfilled, boiling water may be ejected.

3

Special Safety Instructions for the Kettle

- The water level must be between the MAX. and MIN. marks.
- Switch the kettle off before removing it from the base.
- Always ensure that the lid is tightly closed.
- The base and exterior of the kettle must not become wet.
- Kettle body used must match with the kettle base.

First Use of the Kettle

- Before using the kettle for the first time, fill the kettle with cold water and boiled it twice without any additives.

1. Fill the kettle with water. Do not overfill. Use the water level indicator.
 2. Place the kettle on the base.
 3. Electrical connection
 - Check whether the electrical voltage which you intend to use is the same as that of the kettle. Details can be found on the label on the base of the kettle.
 - Only connect the kettle to a properly installed 220-240V 50/60Hz socket.
 4. Switch the kettle to position '1'. The control lamp on the water indicator shows that the water is being boiled.
 5. After boiling, the kettle switches off automatically.
- Disconnect the kettle from the mains electricity supply.
- Do not open the lid when pouring.
- This appliance is intended to be used in household and similar applications such as:
- Staff kitchen areas in shops, offices and other working environments;
 - Farm houses;
 - By clients in hotels, motels and other residential type environments;
 - Bed and breakfast type environments.

Cleaning

Always remove the plug from the mains supply before cleaning the kettle. The exterior of the kettle should be cleaned, if necessary, with a slightly damp cloth without additives. The calcium filter can be removed for cleaning

Power Supply:

220-240V~ 50/60Hz 1850-2200W

4