

# CRYSTAL

## HƯỚNG DẪN SỬ DỤNG BẾP ĐIỆN TỬ *Model: LY-T39*



Chân thành cảm ơn Quý khách đã lựa chọn sản phẩm Bếp điện từ CRYSTAL LY-T39.

Vui lòng đọc sách hướng dẫn sử dụng này một cách cẩn thận trước khi bật thiết bị.

Việc tuân thủ các hướng dẫn trong sách hướng dẫn này sẽ giúp Quý khách sử dụng thiết bị đúng quy cách.

Luôn lưu giữ và để sách hướng dẫn sử dụng này ở nơi dễ lấy.

## 1. THÔNG TIN SẢN PHẨM

- Bảo vệ môi trường: không độc hại, không gây ô nhiễm.
- Làm nóng nhanh: nguồn điện sẽ tạo ra từ trường trong bếp thông qua cuộn dây đồng được đặt sẵn trong bếp từ và tạo ra cảm ứng lên nồi gây nóng làm sôi nước và chín đồ ăn.
- Bếp sử dụng mặt kính có độ cứng và chịu được nhiệt độ cao, dễ dàng vệ sinh, sử dụng lâu bền.
- Điều khiển chức năng và nhiệt độ theo ý muốn.
- Sử dụng an toàn, có nhiều chức năng: bảo vệ điện áp, bảo vệ quá nhiệt.

## 2. LƯU Ý

- Không chạm tay vào mặt bếp còn nóng sau khi sử dụng.
- Không để bếp vào trong nước để tẩy rửa.
- Nếu dây nguồn bị hỏng, nó phải được thay thế bởi nhà sản xuất, nhân viên bảo hành, người chuyên môn để tránh rủi ro nguy hiểm.
- Để bếp tránh xa tầm tay của trẻ em.
- Luôn có người giám sát khi sử dụng bếp để đun nấu.
- Không đặt giấy, khăn và các vật dụng dễ cháy khác trên bề mặt bếp để phòng gây hỏa hoạn.
- Không để trẻ em hoặc những người mất năng lực hành vi sử dụng bếp.
- Không luồn dây sắt và các vật dụng kim loại khác vào lỗ thoát khí để tránh bị điện giật.
- Nếu mặt bếp bị vỡ, vui lòng ngừng sử dụng và gửi tới trung tâm bảo hành.
- Sau khi tắt bếp, quạt vẫn tiếp tục hoạt động để tản nhiệt, vui lòng chỉ rút dây nguồn sau khi quạt dừng hoạt động.
- Khi đáy nồi bị biến dạng, vui lòng thay thế nồi để tránh tình trạng nhiệt độ cục bộ trên bề mặt bếp do nhiệt phân bố không đồng đều, dẫn tới làm hỏng mặt bếp.

## 3. LỰA CHỌN NỒI – CHẢO

- Thép, gang, sắt tráng men, thép không gỉ với đáy nồi/chảo phẳng đường kính từ 12 đến 20cm.
- Quý khách vui lòng sử dụng nồi/chảo phụ kiện đi kèm theo bếp hoặc nồi/chảo đúng chất liệu nêu trên thay vì sử dụng các loại nồi khác.



- Quý khách vui lòng tuân thủ các yêu cầu dưới đây:
- Nồi/chảo phải phù hợp với bếp từ.
- Nồi/chảo nên được thử trước khi mua để chắc chắn không có bất kỳ hiện tượng bất thường nào.
- Nồi/chảo khi mua phải có đáy phẳng và đi kèm với nắp có lỗ thoát hơi.

#### 4. CÁC CHỨC NĂNG CHÍNH

| PHÍM CHỨC NĂNG                                                                      | CHỨC NĂNG                                                                                                                                                         |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | Mở/Tắt hoạt động của bếp.                                                                                                                                         |
|     | Cảm ứng trượt điều chỉnh tăng-giảm công suất.<br>Có 10 mức điều chỉnh công suất (W):<br>200-400-600 -800 -1000 -1200-1400-1600-1800+P                             |
|    | Cài đặt hẹn giờ.                                                                                                                                                  |
|     | Điều chỉnh tăng, giảm thời gian hẹn giờ. Mỗi lần nhấn [+] [-], thời gian tăng hoặc giảm 1 phút, và mỗi lần nhấn giữ 3 giây, sẽ điều chỉnh tăng hoặc giảm 10 phút. |
|  | Nhấn giữ 3 giây để kích hoạt chế độ khóa trẻ em.<br>Nhấn giữ thêm 3 giây để mở khóa tính năng này.                                                                |
|  | Chế độ giữ ấm 60°C.                                                                                                                                               |
|  | Chế độ tạm dừng.                                                                                                                                                  |
|  | Chức năng nấu nhanh Booster:<br>Nhấn phím này để bếp chuyển sang hoạt động công suất tối đa liên tục trong 5 phút.                                                |

## 5. KHẮC PHỤC SỰ CỐ

| HIỆN TƯỢNG                                                             | VẤN ĐỀ CẦN KIỂM TRA                                                                                                                                                | KHẮC PHỤC                                                                                                                   |
|------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Sau khi cắm điện, bếp không có phản hồi, màn hình hiển thị không sáng. | 1. Phích cắm đã được cắm chặt vào ổ điện chưa?<br>2. Dây nguồn và ổ cắm nguyên vẹn?<br>3. Ổ cắm có điện không?                                                     | Vui lòng kiểm tra nguyên nhân cẩn thận. Nếu sự cố không thể khắc phục, vui lòng liên hệ với Trung tâm Bảo hành và sửa chữa. |
| Bếp đột ngột ngừng làm nóng trong khi sử dụng.                         | 1. Nhiệt độ xung quanh có cao không?<br>2. Lỗ hút/xả khí bị tắc nghẽn<br>3. Hết thời gian hẹn giờ trước<br>4. Bếp được sử dụng liên tục hơn 2 tiếng                | 1. Di chuyển bếp đến nơi có nhiệt độ thấp hơn<br>2. Kiểm tra lỗ hút/xả khí<br>3. Bình thường<br>4. Bình thường              |
| Bếp lên nguồn nhưng không hoạt động.                                   | 1. Bảng mạch bị hỏng<br>2. Mô đun nhiệt bị hỏng                                                                                                                    | Vui lòng kiểm tra nguyên nhân cẩn thận. Nếu sự cố không thể khắc phục, vui lòng liên hệ với Trung tâm Bảo hành và sửa chữa. |
| Bếp không làm nóng.                                                    | 1. Nồi/chảo đang sử dụng trên bếp không tương thích hoặc không có nồi/chảo trên bếp đang được sử dụng?<br>2. Nồi/chảo có đường kính đáy nhỏ hơn yêu cầu tối thiểu. | 1. Đặt nồi/chảo vào đúng khu vực nấu/khu vực nhiệt trên mặt bếp.<br>2. Thay thế nồi/chảo phù hợp với bếp.                   |

## 6. MÃ CẢNH BÁO

| MÃ HIỂN THỊ | VẤN ĐỀ                                                              |
|-------------|---------------------------------------------------------------------|
| E0          | Không đặt nồi/chảo lên bếp hoặc nồi/chảo đang sử dụng không phù hợp |
| E1/ E2      | Điện áp quá thấp/ Điện áp quá cao                                   |
| E3          | Cảm biến bề mặt bị hỏng hoặc ngắn mạch                              |
| E4          | IGBT bị hỏng hoặc ngắn mạch                                         |
| E5          | Nhiệt độ bề mặt bếp quá cao                                         |
| E6          | IGBT bị quá nhiệt                                                   |
| E7          | Lỗi cảm biến bề mặt                                                 |

## 7. BẢO DƯỠNG VÀ VỆ SINH

- Rút phích cắm điện trước khi vệ sinh bếp. Không lau chùi bếp cho đến khi mặt bếp đã nguội hẳn.
  - Vệ sinh mặt kính, bảng điều khiển và vỏ ngoài của bếp.
    - Đối với các vết bẩn nhẹ, vui lòng sử dụng vải mềm.
    - Đối với các vết dầu mỡ, vết bẩn khó làm sạch, vui lòng sử dụng vải ẩm sạch và chất tẩy rửa trung tính.
  - Để quạt giải nhiệt hoạt động ổn định, vui lòng sử dụng bàn chải hoặc que bông để vệ sinh bụi bẩn thường xuyên.
  - Không sử dụng nước hoặc chất lỏng để rửa trực tiếp bếp để tránh gây hư hỏng.
  - Để bảo vệ bếp hoạt động ổn định, phải đảm bảo phích cắm tiếp xúc tốt với ổ cắm điện.
  - Không rút phích cắm ra khỏi ổ cắm đột ngột trong lúc bếp đang hoạt động. Để kéo dài tuổi thọ của bếp, vui lòng tắt bếp bằng cách nhấn nút [Mở/Tắt] trước khi rút phích cắm.
  - Chỉ rút phích cắm ra khỏi ổ điện sau khi quạt giải nhiệt ngừng hoạt động.
  - Nếu Quý khách có dự định không sử dụng bếp trong một khoảng thời gian dài, vui lòng rút phích cắm ra khỏi ổ điện và cất bếp ở nơi sạch sẽ, thoáng mát.
-

# CRYSTAL

## INSTRUCTION MANUAL

### INDUCTION COOKER

*Model: LY-T36*



Thank you for purchasing this induction cooker CRYSTAL LY-T39.

Please thoroughly read through this instruction manual before use and store it carefully for future use.

## 1. PRODUCT FEATURES

- Environmental protection: non-toxic and pollution-free when work.
- Fast heating: this product uses the principle of electromagnetic induction to directly heat the bottom of the pot, with high thermal efficiency and fast speed.
- Using high hardness, high temperature resistant. The micro crystal panel, easy to clean and durable.
- Microcomputer control, free control of firepower and temperature
- Multiple protection functions such as over-voltage, under-voltage, over-temperature, fan delay heat dissipation, etc., making it safer to use.

## 2. ATTENTION

- The micro crystal panel of this machine shows high temperature after used, please do not touch it.
- Please do not put it clean directly in water.
- If the power cord is damaged, please go to a special store to replace it. At the same time, please use a special cord to replace it.
- Please use this machine in a place avoid reach of children.
- Someone must be supervised during use.
- Please do not put paper, towel and other flammable materials on the stove to heat, so as not to cause the fire to go out.
- Please do not let children or people without conscious behavior ability use it.
- Do not insert iron wires and other items into the air outlet and exhaust vents to avoid electric shock.
- If the crystal board is damaged, please stop using it and send it to the repair point for repair.
- After each use, please wait for the fan to fully dissipate heat inside the machine, and then unplug the power plug after the fan stops working
- When the bottom of the pot used is deformed, please replace the pot to avoid the local temperature of the micro crystal plate surface being too high due to uneven heating and damaging the panel.

## 3. SELECTION OF COOKWARE

- Steel, cast iron, enameled iron, stainless steel, flat-bottom pans/pots with diameter from 12 to 20cm.
- Suggest to use the required pot, do not try to use other pot instead (especially pressure sensors vessels).



• Please kindly according to the below requirement if necessary to use the vessel is not equipped:

- Pan/Pot must be suitable for induction cooker.

- Pan/Pot should be tried out if it's bought by self to see if there are unusual phenomena.

- Pan/Pot bought by self should be flat and come with the cover with gas vent.

#### 4. FUNCTION

| BUTTON                                                                              | FUNCTION DESCRIPTION                                                                                                                                                                     |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | To enter the standby state or stop working.                                                                                                                                              |
|     | This function has 10 levels of firepower adjustable, respectively: 200-400-600 -800 -1000 -1200-1400-1600-1800+P.                                                                        |
|    | Press the timer during working to enter the time setting state of timing shutdown.                                                                                                       |
|     | Time adjustment. Each time you press [+] [-], the time increases by 1 minute, and each time you press and hold it increases or decreases by 10 minutes, and the long press is effective. |
|  | Long press 3s to lock the working state of the machine, long press 3s in the locked state to unlock                                                                                      |
|  | You can press this function to keep warm 60°C, if you want to cancel keep warm function, press it again.                                                                                 |
|  | Pause. You can press this function to stop working for a while, and press again to go on working.                                                                                        |
|  | Booster. You can press this function to enter max power to keep working 5 minutes, after 5 minutes it will recover to the power before press this function.                              |

## 5. TROUBLE SHOOTING

| FAILURE                                                  | CAUSE ANALYSIS                                                                                                                                                                     | REPAIR METHOD                                                                                                             |
|----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| No power.                                                | 1.The power cord is not plugged in properly.<br>2.Are the sockets and leads intact?<br>3.Whether the power supply is ok.                                                           | Check the root causes carefully. If the problem can't be fixed, please contact service center for checking and repairing. |
| Suddenly stop heating during use                         | 1.Is the surrounding temperature high?<br>2.Whether the suction and exhaust vents are blocked.<br>3.Whether the timing is set.<br>4.Is it used continuously for more than 2 hours. | 1. Move to a place with a lower temperature.<br>2. Drain the blockage.<br>3. Normal.<br>4. Normal.                        |
| It can be turned on after power-on but does not heat up. | 1.The circuit board is damaged.<br>2.Damaged heating plate.                                                                                                                        | Check the root causes carefully. If the problem can't be fixed, please contact service center for checking and repairing. |
| No heating.                                              | 1. There is no pot on the induction cooker.<br>2. The pot used do not meet the requirements.                                                                                       | 1. Place a suitable pot on the heating unit.<br>2. Replace with suitable pots.                                            |

## 6. FAULT CODE

| CODE   | MEANING                                                              |
|--------|----------------------------------------------------------------------|
| E0     | No pot or the pot is without induction, or the pot is not available. |
| E1/ E2 | Low-voltage protection/ Over-voltage protection.                     |
| E3     | Surface sensor open or short circuit protection.                     |
| E4     | IGBT sensor open or short circuit protection.                        |
| E5     | Surface overheating protection.                                      |
| E6     | IGBT overheating protection.                                         |
| E7     | Surface sensor failure protection.                                   |

## 7. MAINTENANCE AND DAILY CARE

- Remove the power plug prior to clean the unit. Do not clean it until the surface cools down.
  - Glass Plate, Panel and Shell.
    - Soft Cloth for slight stain.
    - For greasy, dirt, blot by using a clean damp cloth with neutral detergent.
  - While the radiator-fan working, dust and dirt would remain on the gas vent, please clean it by brush or cotton stick regularly.
  - Remember do not washing the unit by water directly to avoid damaging.
  - To protect induction cooker, to be sure to have a good contact between plug and socket before using.
  - Do not pull out the power cord directly during operation. To extend the appliance's using life, press the [On/Off] button first, then pull out the power cord.
  - In order to make operating time longer, the fan would still work for cooling the plate, is better to plug out after the fan stops working.
  - Please pull out the power cord and put it away when not used for a long time.
-