

AVA

MÁY SẤY TÓC
RYC-7044



HƯỚNG DẪN SỬ DỤNG **RCY-7044**

Vui lòng đọc kỹ hướng dẫn sử dụng trước khi dùng sản phẩm.

THÔNG SỐ KỸ THUẬT

- Model: RCY-7044
- Công suất: 1800W
- Nguồn điện: 220-240V, 50-60Hz

CÁC TÍNH NĂNG

- + Cài đặt Tắt - Mát - Thấp - Cao
- + Nút sấy mát
- + Bảo vệ quá nhiệt
- + Đầu sấy
- + Tay cầm có thể gập lại

HƯỚNG DẪN AN TOÀN QUAN TRỌNG

***Vui lòng đọc kỹ hướng dẫn sử dụng này trước khi sử dụng:**

- Trước khi kết nối thiết bị lần đầu tiên, hãy kiểm tra xem điện áp ghi trên nhãn thông số có tương ứng với điện áp nguồn trong nhà bạn không.
- Luôn rút phích cắm thiết bị khỏi nguồn điện trước khi vệ sinh và khi không sử dụng.
- Để tránh rủi ro bị điện giật, không nhúng thiết bị vào nước hoặc bất kỳ chất lỏng nào khác.
- Không sử dụng thiết bị gần bồn tắm, vòi sen hoặc hồ bơi.
- Không xịt các sản phẩm dạng bình xịt khi máy sấy tóc đang hoạt động.
- Trẻ em nên được giám sát để đảm bảo rằng chúng không nghịch thiết bị.
- Không sử dụng các phần đính kèm khác với phần được cung cấp.
- Không bao giờ mang hoặc treo thiết bị bằng dây.
- Không hoạt động sau sự cố hoặc hư hỏng dây.
- Không cố gắng sửa chữa, điều chỉnh hoặc thay thế các bộ phận trong thiết bị. Sửa chữa thiết bị bị trục trặc ở trung tâm bảo hành gần nhất.

QUAN TRỌNG:

- Giữ tóc của bạn tránh xa vùng lân cận của cửa gió vào. Giữ cho bộ lọc không khí đầu vào không có bụi và lông tơ.
- Không che đầu vào hoặc cửa thoát khí nếu không máy sấy tóc có thể quá nóng.

HƯỚNG DẪN SỬ DỤNG

- Rút dây hoàn toàn.
- Cắm phích cắm vào nguồn điện.
- Chọn chế độ tốc độ mong muốn bằng công tắc tốc độ.

Vị trí 0: TẮT.

Vị trí 1: Gió mát, thoải mái sấy khô và tạo kiểu vào mùa hè.

Vị trí 2: Công suất thấp, nhiệt độ thấp để sấy khô và tạo kiểu nhẹ nhàng.

Vị trí 3: Công suất cao, nhiệt độ cao để sấy khô nhanh.

Nút sấy mát: gió nóng thay đổi thành gió mát khi bạn nhấn nó mọi lúc.

CHĂM SÓC VÀ VỆ SINH

- Tắt thiết bị, rút phích cắm khỏi nguồn điện và để nguội hoàn toàn.
- Không sử dụng chất tẩy rửa ăn mòn.

BẢO QUẢN

- Đảm bảo rằng máy sấy tóc khô và mát hoàn toàn.
- Không quấn dây xung quanh thiết bị, vì điều này có thể gây hư hỏng.
- Để máy ở nơi khô ráo, thoáng mát.

FEATURES

- 220-240V, 50/60Hz, 1800W
- Off-Cool-Low-High settings
- Cool shot button
- Overheating protection
- With concentrator
- Foldable handle

IMPORTANT SAFEGUARDS

- Please read this instruction manual carefully before use.
- Before connecting the appliance for the first time check that voltage indicated on the rating label corresponds to the mains voltage in your home.
- Always unplug the appliance from the power supply before cleaning and when not in use.
- To prevent risk of electric shock, do not immerse the appliance in water or any other liquids.
- Do not use the appliance in immediate proximity to a bath, a shower or a swimming pool.
- Do not spray aerosol products when the hair dryer is in operation.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use other attachments than those supplied.
- Never carry or suspend the appliance by the cord.
- Do not operate after malfunction or cord damage.
- Do not attempt to repair, adjust or replace parts in the appliance. Repair the malfunctioning appliance in the nearest service center.

IMPORTANT:

- Keep your hair away from the immediate vicinity of the air inlet opening. Keep air inlet filter dust and fluff free.
- Do not cover air inlet or air outlet otherwise the hair dryer may overheat.

INSTRUCTION FOR USE

- Fully unwind the cord.
- Insert the plug into the power supply.
- Select desired speed mode using the speed switch.

Position 0: OFF.

Position 1: Cool wind, comfortable for drying and styling in summer.

Position 2: Low power, low temperature for gentle drying and styling.

Position 3: High power, high temperature for quick drying.

Cool shot: Hot wind change to cool wind when you press it all the time.

CARE AND CLEANING

- Switch off the appliance, unplug from the power supply and allow it to cool fully.
- Do not use abrasive cleaners.

STORAGE

- Ensure that the hair dryer is completely cool and dry.
- Do not wrap the cord around the appliance, as this may cause damage.
- Keep the appliance in a cool, dry place.
