



Important Presentation

- Please read this booklet carefully before using the trimmer.
- Please don't wash the trimmer by water.
- Keep dry of the trimmer.
- Keep the trimmer at the temperatures between 5°C-35°C.
- Please take out the battery if won't use the trimmer within a long time.
- Please take good care of the instruction for future Reference.

Caution

- This personal grooming device is designed to trim the nose and ear hair. Do not attempt to use it for any other purpose.
- Do not insert the device further into your nostril or an ear hole than narrow tip on the outer blade also, do not press the trimmer forcefully into your nostril or ear holes. Do not attempt to use the device if the outer blade frame or blade are deformed or damaged, as injury to your nostril or an ear hole may occur. The blades have been precisely manufactured. Do not subject them to excessive force, impart, etc. If use once a week for approximate 1 minute at one time, the life of the

blade is about 2 years.

Battery place

- Open the battery cover.
- Use one 1.5V AA battery or other high power battery.
- Put the battery into the battery cover according to the + and - poles.
- Make sure the + and - poles of the battery are corresponding to that of the box. If the battery is not correctly placed, the nose trimmer would not work.
- You may discard the battery when it's empty. Do not throw the battery away with the normal household waste. Please hand it in to the official recycle bin.

Using the trimmer

- Push the switch upward to "On" to turn on the device and carefully insert the tip of the fixed blade into your nostril or an ear hole to trim the nose or ear hair.
- Push the switch backdown to turn off the device, then put on the protect cover.
- Please change the blade once two years in order to keep the ideal trimming effect.

Maintenance

- Be sure that the switch is turned off before re-moving, replacing or cleaning the blade.
- To remove the outer blade frame, turn it anticlockwise and pull upward.
- Detach the fixed blade from the moving blade and remove any cut hairs, dust, etc with the cleaning brush.
- Replace the outer blade frame to the body, match the mark and turn clockwise until it clicks in.

Thông tin cơ bản

- Đọc kỹ hướng dẫn trước khi sử dụng máy
- Không cọ rửa máy với nước
- Giữ máy luôn khô ráo
- Để máy ở nơi nhiệt độ từ 5°C - 35°C
- Tháo pin ra khỏi máy nếu không dùng máy trong một thời gian dài
- Giữ lại hướng dẫn sử dụng để tham khảo thêm khi cần thiết

Lưu ý

- Thiết bị chăm sóc cá nhân này được thiết kế để tỉa lông mũi, lông tai. Không nên sử dụng vào các mục đích khác.
- Không đưa máy vào quá sâu trong lỗ mũi hoặc lỗ tai, vượt quá độ dài phần đầu hẹp của lưỡi tỉa, không dùng sức để ấn máy vào trong lỗ mũi hay lỗ tai. Không sử dụng khi đầu tỉa bị hư hỏng hoặc biến dạng tránh nguy cơ gây tổn thương cơ thể. Lưỡi tỉa đã được thiết kế chuẩn xác, không được tự ý tháo rời hoặc thay đổi máy. Nếu sử dụng 1 lần/tuần, 60s/lần sử dụng thì lưỡi cạo của máy sẽ có tuổi thọ 2 năm.

Hướng dẫn thay pin

- Mở nắp pin.
- Sử dụng pin loại 1.5V AA hoặc các loại pin công suất cao khác.

- Lắp pin vào đúng vị trí theo các cực âm (-) dương (+). Chú ý lắp các đầu pin theo đúng ký hiệu trên máy, nếu không máy sẽ không thể hoạt động được.
- Có thể thay thế khi pin đã được dùng hết. Chú ý không vứt pin đã hết cùng với các loại rác thải sinh hoạt bình thường, để đúng nơi quy định cho mục đích tái chế.

Hướng dẫn sử dụng máy

- Đẩy công tắc lên vị trí "On" để bật máy và cần thận đưa máy vào trong lỗ mũi hoặc lỗ tai để tỉa lông mũi hoặc lông tai
- Đẩy công tắc về vị trí có để tắt máy, đóng nắp bảo vệ.
- Thay mới lưỡi tỉa sau mỗi 2 năm sử dụng để đảm bảo hiệu quả sử dụng cao nhất

Hướng dẫn vệ sinh máy & bảo trì

- Phải đảm bảo máy đã được tắt trước khi tháo rời, thay thế hoặc vệ sinh lưỡi tỉa.
- Để tháo khung bên ngoài của lưỡi tỉa, xoay nhẹ ngược chiều kim đồng hồ và nhắc lên.
- Tháo rời lưỡi tỉa đi động bên trong để vệ sinh máy, dùng chổi đi kèm trong hộp máy để loại bỏ râu tóc hay bụi bẩn sau khi sử dụng.
- Lắp các bộ phận của máy vào vị trí như ban đầu, xoay nhẹ khung bên ngoài của lưỡi tỉa theo chiều kim đồng hồ tới khi nó khớp chặt vào thân máy.