

How to USE



*Compatible with wireless charging standard



Press the power button to activate charging on your device(s)




Please do not charge more than 2 devices at once (wireless charger is included)

Blinking blue light indicates Quick Charge/Power Delivery is activated



Blinking light indicates recharging.
Solid light indicates fully charged.


How to Recharge



Connect the input port with either the Type-C or Micro USB charging cable.

When power bank stops working, please reset it by recharging your power bank

Connect the charging cable to a universal USB AC adapter.



Adapter not included