

The Smartest Network Device

Quick Installation Guide

Wireless Adapter

Suitable for: N300UM, N150USM


V1.0 | 1712

Copyrights © TOTOLINK All rights reserved. Website: <http://www.totolink.net>
Information in this document is subject to change without prior notice.

LAN Adapter Physical Connection Diagram

Please insert the wireless adapter to you PC before driver installation.

USB LAN adapter connection.



Plug wireless LAN USB adapter in the PC's USB interface.

Note






Computer found the wireless LAN adapter hardware, need to install the driver.

For more information, please visit www.totolink.net.

PRODUCTS | SUPPORT | NEWS | ABOUT US | A2000UA

Instruction of LAN Adapter Driver Installation

- Put into the CD
- Double-click the CD drive letter, choose the corresponding model NO. with correct system type, then click "Install".
- Click "Next"
- Please waiting for a few seconds.
- Click "Finish", the driver program is installed successfully.

Windows 10 Wireless Network Configuration

- Right-click the network icon in the system tray and select "Open Network and Sharing Center".
- Click "Change adapter settings" in the Network and Sharing Center.
- Right-click the WLAN 9 adapter and select "WLAN 9 Properties".
- Click "Change adapter settings" in the WLAN 9 Properties window.
- Click "Next" in the Broadband Connection dialog.
- Click "Next" in the network security key dialog.
- Click "Connect" in the network status window.

Windows 7 Wireless Network Configuration

- Right-click the network icon in the system tray and select "Open Network and Sharing Center".
- Click "Change adapter settings" in the Network and Sharing Center.
- Right-click the Wireless Network Connection and select "Wireless Network Connection Properties".
- Click "Connect" in the network status window.
- Type the network security key in the "Connect to a Network" dialog.
- Click "OK" in the network status window.