

USER'S GUIDE

LM-TF003(Seconds Cartoon, Multifunction Sport Watch)

EL Backlight

Stopwatch

World Time

Countdown Timer

Low Power Indicator

5 Alarms
 5 Alarms
 5 Alarms
 5 Alarms
 7 Alarms

100 Year Calendar

Chime

200M Water Resistant

Battery(CR2016)

BUTTONS

 Button operation are indicated using the letters shown in the illustration




- C -- EL backlight / -
- D -- Start / Stop / +

ATTENTION

- 1. Never try to open the case or remove its back cover.
- Do not operate buttons underwater.
- Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
- Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
- Avoid exposing the watch to temperature extremes.
- Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
- 7. Avoid to wear the watch in electromagnetic, static

DISPLAY

The screen shown in below:



BACKLIGHT

 The backlight that uses an EL (electroluminescent) cause the display to glow for easy reading in the dark.

Use EL Backlight

In the timekeeping mode, press C't oi liumate the display about 3 seconds.

LOW POWER

 If the battery voltage level is insufficient, the icon "ED" will appear to remind to replace a new battery.



LARMES TRANSFORMERS

MODE SELECTION

 Press "B" to change mode to mode in the following sequence:

sequence: Timekeeping Mode - Stopwatch Mode - Countdown Mode - Alarm Mode - World Time Mode.

(a) TIMEKEEPING

- 12/24H Format:
- Hour, Minutes, Seconds, Day of week, Month, Date;
- 100 years Calendar (2000 ~ 2099).



 1/100 second unit;
 Measuring range: 0'00"00 ~ 99:59'59".



C COUNTDOWN

 Countdown range: 99:59'59" ~ 0'00"00.



d ALARM

- 5 Alarms;
- Hourly time signal;
- The alarm sounds at the preset time each day.



The time for other time zone.





TIMEKEEPING

Time Setting

 In the timekeeping mode, press and hold "A" until the city code will flash(flashing is indicated in the setting mode);



Press "C" or "D" to turn ON/OFF the Daylight Saving Time.



City code - Daylight Saving Time - Seconds - Hour - Minutes - 12/24H Format - Year - Month - Date - Date Format - Key Tone(ON/OFF);

 Press "C" or "D" to select the city code, press and hold to adjust at high speed;



Press "A" to exit the set state after setting (The day of week is automatically displayed in accordance with year, month and date setting).

5. Repeat steps 3 and 4, the selection in the following

Calendar

sequence:

 In the timekeeping mode, press and hold "D" to display: Month, Date.



Press "B" to select the Daylight Saving Time;



World Time Form					
City code	City	GMT Differential	Other major cities in same time zone		
WLG	Wellington	+12	Christchurch, Nauru Island, Nadi		
NOU	Noumea	+11	Portvila		
SYD	Sydney	+10	Melbourne, Guam, Rabaul		
ADL	Adelaide	+9.5	Darwin		
TYO	Tokyo	+09	Seoul, Pyongyang		
HKG	Hong Kong	+08	Singapore, Kuala Lumpur, Beijing, Taipei, Manila		
BKK	Bangkok	+07	Jakarta, Phnom Penh, Hanoi, Vientiane		
RGN	Yangon	+6.5			
DAC	Dhaka	+06	Colombo		
DEL	Delhi	+5.5	Mumbai, Kolkata, Colombo		
KHI	Karachi	+05	Male		
KBL	Kabul	+4.5			
DXB	Dubai	+04	Abu Dhabi, Muscat		
THR	Tehran	+3.5	Shiraz		

City code	City	GMT Differential	Other major cities in same time zone
JED	Jeddah	+03	Kuwait, Aden, Addis Ababa, Nairobi, Moscow
CAI	Cairo	+02	Athens, Helsinki, Istanbul, Beirut, Damascus, Cape Town
JRS	Jerusalem	+02	
PAR	Paris	+01	Milan, Rome, Amsterdam, Madrid, Algiers
LON	London	+00	Dublin, Lisbon, Casablanca, Dakar, Abidjan
RIO	Rio de Janeiro	-03	Sao Paulo, Buenos Aires, Brasilia, Montevideo
ccs	Caracas	-04	La Paz, Santiago, Port Of Spain
NYC	New York	-05	Montreal, Detroit, Miami, Boston, Panama City
CHI	Chicago	-06	Houston, Dallas/Fort Worth, New Orleans,
DEN	Denver	-07	El Paso, Edmonton
LAX	Los Angeles	-08	San Francisco, Las Vegas, Vancouver, Seattle
ANC	Anchorage	-09	Nome
HNL	Honolulu	-10	Papeete
PPG	Pago Pago	-11	Pago Pago

