







<p style="text-align: center;">USER MANUAL- NECKBAND BLUETOOTH HEADSET</p>  <p style="text-align: center;">Z706A</p>	<p>Quick Start The headset consists of the following components:</p>  <ol style="list-style-type: none"> 1. Toggle switch 2. Neckband 3. Left headset body 4. Right headset body 5. Microphone 6. MFB (Multi Function Button) 7. Volume + 8. Volume - 9. Micro USB charging port 10. LED indicator 11. Ear cap <p style="text-align: center;">1</p>	<p>Fully charge the headset before using. For details about how to charge the headset, see "Charger and Battery" in this manual. Meanwhile, choose the cell phone that is compatible with the headset or other Bluetooth devices to pair with the headset. For details about pairing, see "Basic Operations".</p> <p>Tip: Keep the headset away from your credit card or .other magnetic storage media; otherwise, the stored information may be lost due to demagnetization.</p> <p>How to connect with the Bluetooth headset Z706A</p> <ol style="list-style-type: none"> 1. When the headset is in power-off state, turn the toggle switch upward. 2. Now the headset Z706A is power on and auto enters into a pairing mode with red & blue light flash alternately along with a sound "Power on , pairing".  <p style="text-align: center;">Toggle switch</p> <ol style="list-style-type: none"> 2. Open the Bluetooth software of your phone, searching the headset Z706A. 3. Find the Z706A, click it to finish the connection. You will hear a sound "connected" after paired successfully. <p style="text-align: center;">2</p>	<p>Basic Operations</p> <p>Power On: When the headset is in power-off state, push the toggle switch upward to power on the headset. You will hear voice "Power on, Pairing", and the headset automatically enters the pairing state with red & blue light flash alternately.</p> <p>The indicators keep Red for 2 seconds and then off if .other magnetic storage media; otherwise, the stored information may be lost due to demagnetization, accompanied by the voice prompt "Power off".</p> <p>Connecting: After the headset enters the pairing state, search the Bluetooth on cell phone, and click Z706A to Connect it, accompanied by a voice prompt "Connected".</p> <p>Answer a Call: Press the MFB button once to end an on-going call.</p> <p>Reject a Call: When there is an incoming call, you can double click the MFB button to reject the call.</p> <p>Conversation Transfer: If you press the MFB button for 1 second then release during a conversation, the conversation is switched to the mobile phone. Repeat same step, the conversation can be switched to Z706A again.</p> <p style="text-align: center;">3</p>	<p>Automatic Re-Connect: When power on Z706A, the Z706A is automatically connected with the last cell phone that Z706A has previously paired with. If the cell phone is in connection range and its Bluetooth turned on.</p> <p>Last Number Redialing: At the standby or music state, double click the MFB button to redial the last dialed number.</p> <p>Music Play/Pause: Press the MFB button once to play music, press again to pause music.</p> <p>Volume Up: Press the volume + button once to increase the volume by one grade. If the volume reaches the maximum, a tone sound is heard.</p> <p>Volume Down: Press the volume - button once to decrease the volume by one grade. If the volume reaches the minimum, a tone sound is heard.</p> <p>Previous Song: If you press the volume "–" button for 1 second during music playing, the previous song is played.</p> <p>Next Song: If you press the volume "+" button for 1 second during music playing, the next song is played.</p> <p style="text-align: center;">4</p>	<p>Three-Wall Calling: If a call (B) is coming in during an on-going call (A), you can press the MFB button to end A and answer B. Or, you can press the MFB button twice to hold A and answer B, and press the MFB button twice again to switch between A and B. During three-calling, you can press the MFB button to end the current call and recover the held call.</p> <p>iOS Battery Indicator: After the headset is successfully connected to an iOS device, the IOS device displays the current battery status of Z706A headset.</p> <p>Power Off: When the headset is in power on state, push the toggle switch downward, the indicators keep red for about 2 seconds and then off, accompanied by the voice prompt "Power off".</p> <p>Enabling/Disabling Voice Control: Press the MFB button for 1 second and release, a tone sound is heard and voice control is enabled. Press the MFB button for one second again, and voice control is disabled.</p> <p>1-to-2 Multipoint Connecting: Pair Z706A with cell phone A, and disable the Bluetooth function of A. Pair Z706A with cell phone B and connect successfully, then enable the Bluetooth function of A. If your</p> <p style="text-align: center;">5</p>	<p>cell phone supports the automatic re-connection function, the Z706A will be automatically connected to A. Alternatively, you can click the headset Z706A to re-connect to A. At this time, the Z706A can be connected to A and B at the same time.</p> <p>Reset factory setting: when charging, press the MFB for 5 seconds, the Red LED blinks 3 times.</p> <p>The lost/Out of range warning: There will be vibration after abnormal disconnection or out of coverage distance.</p> <p>Charging the Battery The headset is embedded with non-removable rechargeable battery. Do not attempt to remove the battery from the headset; otherwise, the headset may be damaged. If the headset is not used in a long time, keep it in a dry and well-ventilated place, and charge the headset once every two months.</p> <p>1.If the red indicator blinks every 8 seconds, the headset battery is low. If the headset continues to work, it may be automatically powered off. At this time, you need to charge the headset by connecting the charging cable to the charging port on the headset. 2.Connect the charger to the power socket.</p> <p style="text-align: center;">6</p>	<p>3.The indicator keep Red on when the headset is being charged. If the charging is not started yet, disconnect the headset from the power socket, and reconnect the headset again. It takes about 2 hours to fully charge the headset. After charging fully, the red indicator is off, and the blue indicator is on. At this time, you can disconnect the charger from the power socket and headset.</p> <p>Warning: Only use the recommended charger if possible. Other chargers may violate the warranty terms of the equipment and results in danger. If the charging cable is delivered with the headset, connect the cable to a CCC-certified charger or computer to charge the headset.</p> <p>A fully charged battery can provide up to 21 hours of Music Time, 15 hours of talk time, or 360 hours of standby time. The actual talk time and standby time may vary with different cell phones, settings, use methods, and environment.</p> <p style="text-align: center;">7</p>	<p>Troubleshooting</p> <table border="1"> <thead> <tr> <th>Problem Description</th> <th>Cause</th> <th>Solution</th> </tr> </thead> <tbody> <tr> <td>Power on function is failed.</td> <td>The battery is exhausted. Toggle switch is not in right position.</td> <td>Use the charger to fully charge the battery. Turn the toggle switch again.</td> </tr> <tr> <td>Charging function is failed.</td> <td>The charging port is not properly connected.</td> <td>Reconnect the charging port.</td> </tr> <tr> <td>Power off function is failed.</td> <td>The headset program is in error due to an incorrect operation.</td> <td>Use the charger to charge and reset the headset.</td> </tr> <tr> <td>The headset cannot be searched or pairing fails.</td> <td>The headset does not enter into the pairing state. The Bluetooth application of the cell phone is in error.</td> <td>Enable the headset to enter into the pairing state. Close the cell phone and start again to pair the cell phone with the headset.</td> </tr> </tbody> </table> <p style="text-align: center;">8</p>	Problem Description	Cause	Solution	Power on function is failed.	The battery is exhausted. Toggle switch is not in right position.	Use the charger to fully charge the battery. Turn the toggle switch again.	Charging function is failed.	The charging port is not properly connected.	Reconnect the charging port.	Power off function is failed.	The headset program is in error due to an incorrect operation.	Use the charger to charge and reset the headset.	The headset cannot be searched or pairing fails.	The headset does not enter into the pairing state. The Bluetooth application of the cell phone is in error.	Enable the headset to enter into the pairing state. Close the cell phone and start again to pair the cell phone with the headset.
Problem Description	Cause	Solution																					
Power on function is failed.	The battery is exhausted. Toggle switch is not in right position.	Use the charger to fully charge the battery. Turn the toggle switch again.																					
Charging function is failed.	The charging port is not properly connected.	Reconnect the charging port.																					
Power off function is failed.	The headset program is in error due to an incorrect operation.	Use the charger to charge and reset the headset.																					
The headset cannot be searched or pairing fails.	The headset does not enter into the pairing state. The Bluetooth application of the cell phone is in error.	Enable the headset to enter into the pairing state. Close the cell phone and start again to pair the cell phone with the headset.																					

<p style="text-align: center;">HƯỚNG DẪN SỬ DỤNG- TAI NGHE BLUETOOTH</p>  <p style="text-align: center;">Z706A</p>	<p>Hướng dẫn nhanh Tai nghe của bạn bao gồm các thành phần sau:</p>  <ol style="list-style-type: none"> 1. Nút chuyển đổi 2. Vòng chòang cổ 3. Thân máy bên trái 4. Thân máy bên phải 5. Vị trí Micro 6. Nút đa chức năng 7. Nút tăng âm lượng 8. Nút giảm âm lượng 9. Cổng sạc Micro USB 10. Đèn LED 11. Nút tai. <p style="text-align: center;">9</p>	<p>Luôn sạc đầy trước khi sử dụng. Vui lòng xem hướng dẫn cách sạc trong hướng dẫn này. Cũng lưu ý rằng, bạn nên chọn lựa điện thoại hoặc các thiết bị tương thích với tai nghe. Về cách kết nối giữa các thiết bị, vui lòng xem "vận hành cơ bản" trong hướng dẫn này.</p> <p>Lưu ý: Giữ tai nghe cách xa thẻ tín dụng, hoặc các loại thẻ từ, thiết bị lưu trữ như ổ cứng, thẻ SD,...nếu không sẽ xảy ra tình trạng mất mát dữ liệu đáng tiếc xảy ra.</p> <p>Cách kết nối tai nghe Bluetooth Z706A:</p> <ol style="list-style-type: none"> 1.Khi tai nghe đang ở trạng thái tắt nguồn, gạt nút chuyển đổi lên phía trên để mở. Tai nghe sẽ nhấp nháy đèn đỏ - xanh liên tục cùng với âm thanh thông báo "Power on , pairing". Tai nghe đã sẵn sàng để kết nối.  <p style="text-align: center;">Nút chuyển đổi</p> <ol style="list-style-type: none"> 2. Tìm kiếm tai nghe Bluetooth Z706A ở phần cài đặt Bluetooth trong điện thoại của bạn. <p style="text-align: center;">10</p>	<p>3. Chọn tên tai nghe Z706A và hoàn tất kết nối. Bạn sẽ nghe âm thanh thông báo "connected" sau khi kết nối thành công.</p> <p>Vận hành cơ bản Mở thiết bị: Khi tai nghe đang ở trạng thái tắt nguồn, gạt nút chuyển đổi lên phía trên để mở. Bạn sẽ nghe âm thanh "Power on" được phát ra. Tai nghe sẽ nhấp nháy đèn đỏ - xanh liên tục, lúc này tai nghe đã sẵn sàng để kết nối.</p> <p>Đèn sáng đỏ khoảng 2 giây sau đó sẽ tắt nếu hết thời gian ghép nối 180 giây, lúc này âm báo "Power off" sẽ được phát ra. Tai nghe sẽ tắt.</p> <p>Kết nối tai nghe: Sau khi tai ở được bật lên, bạn vào mục Bluetooth trên điện thoại, tìm tai nghe và kết nối. Khi đó, âm thanh "Connected" được phát ra.</p> <p>Nhận cuộc gọi: Bấm nút đa chức năng 1 lần để nghe cuộc gọi đến.</p> <p>Từ chối cuộc gọi: Bấm nút đa chức năng 2 lần để từ chối cuộc gọi đến.</p> <p>Chuyển cuộc gọi sang điện thoại: Trong lúc thực hiện cuộc gọi, bấm nút đa chức năng 1 giây để chuyển</p> <p style="text-align: center;">11</p>	<p>sang điện thoại. Thực hiện thao tác tương tự để chuyển sang tai nghe.</p> <p>Tự động kết nối lại: Ngay khi được mở nguồn, tai nghe sẽ kết nối với điện thoại đã kết nối trước đó.</p> <p>Gọi số gần nhất: Ở trạng thái rảnh, bấm nút đa chức năng 2 lần để gọi đến số liên lạc gần nhất.</p> <p>Nghe nhạc: Ấn nút đa chức năng 1 lần để nghe nhạc, ấn lần nữa để dừng nghe.</p> <p>Tăng âm lượng: Ấn nút tăng âm lượng để tăng âm lượng lên 1 nấc. Nếu âm lượng đã ở mức lớn nhất, 1 âm báo sẽ được phát ra.</p> <p>Giảm âm lượng: Ấn nút giảm âm lượng để giảm âm lượng 1 nấc. Nếu âm lượng đã ở mức nhỏ nhất, 1 âm báo sẽ được phát ra.</p> <p>Về bài hát trước đó: Nếu bạn ấn nút giảm âm lượng 1 giây trong lúc nghe nhạc, bài hát trước đó sẽ được phát .</p> <p>Tới bài hát tiếp theo: Nếu bạn ấn nút tăng âm lượng 1 giây trong lúc nghe nhạc, bài hát tiếp theo sẽ được phát.</p> <p style="text-align: center;">12</p>	<p>Thực hiện cuộc gọi 3 bên: Nếu cuộc gọi (B) đến khi bạn đang thực hiện cuộc gọi (A), bạn ấn nút đa chức năng 1 lần để kết thúc cuộc gọi (A) và trả lời cuộc gọi (B). Hoặc, bạn có thể ấn nút đa chức năng 2 lần để giữ A, trả lời B, và ấn nút đa chức năng 2 lần lại lần nữa để chuyển đổi qua lại giữa 2 cuộc gọi. Sau đó, bạn ấn nút đa chức năng 1 lần nữa để kết thúc cuộc gọi hiện tại, và quay trở lại cuộc gọi đang giữ kia.</p> <p>Chỉ báo pin trên iOS: Sau khi kết nối thành công với các thiết bị Apple, thiết bị sẽ thể hiện chỉ báo pin trên thanh trạng thái.</p> <p>Tắt nguồn: Tai nghe đang ở trạng thái mở, gạt nút chuyển đổi xuống phía dưới để tắt nguồn. Khi đó, đèn màu đỏ sẽ sáng lên 2 giây và âm báo "Power off" sẽ được phát ra.</p> <p>Kích hoạt/hủy kích hoạt điều khiển bằng giọng nói: Ấn nút đa chức năng 1 giây, 1 âm báo sẽ phát ra, chức năng điều khiển bằng giọng nói đã được bật. Ấn 1 giây lần nữa để tắt chức năng này.</p> <p>Kết nối đa thiết bị: Kết nối điện thoại A với tai nghe. Sau đó, tắt Bluetooth của điện thoại A, kết nối tai nghe với điện thoại B. Lúc này, mở Bluetooth điện thoại A lên, nếu điện thoại của bạn hỗ trợ chức năng</p> <p style="text-align: center;">13</p>	<p>tự động kết nối, tai nghe sẽ tự kết nối với A, nếu không, bấm chọn tên tai nghe Z706A để kết nối. Lúc này, tai nghe sẽ kết nối đồng thời cả A và B.</p> <p>Khôi phục cài đặt gốc: Cắm sạc tai nghe, đồng thời giữ nút đa chức năng 5 giây, đèn đỏ sẽ nhấp nháy 3 lần báo hiệu tai nghe đã được khôi phục về trạng thái ban đầu.</p> <p>Cảnh báo ngoài phạm vi kết nối: Sẽ có cảnh báo rung khi thiết bị bị ngắt kết nối đột ngột hoặc ra ngoài phạm vi kết nối với điện thoại.</p> <p>Sạc tai nghe và pin Tai nghe được gắn chặt với pin. Vui lòng không cố gắng tách rời pin khỏi tai nghe; nếu không, có thể làm hỏng tai nghe. Nếu không sử dụng tai nghe 1 thời gian dài, giữ tai nghe ở chỗ thoáng mát và khô ráo. Sạc tai nghe lần mỗi 2 tháng sau đó.</p> <p>1.Nếu đèn đỏ nhấp nháy 8 giây, điều đó có nghĩa là tai nghe của bạn đã hết pin. Vui lòng sạc tai nghe để tiếp tục sử dụng. 2.Kết nối tai nghe với củ sạc. 3.Khi đang sạc, đèn sẽ sáng màu đỏ. Nếu quá trình sạc chưa được diễn ra, vui lòng kết nối lại với bộ sạc. Mất khoảng 2 tiếng để sạc đầy. Sau đó đèn sẽ chuyển</p> <p style="text-align: center;">14</p>	<p>sang màu xanh, lúc này bạn có thể ngắt kết nối với bộ sạc.</p> <p>Cảnh báo: Chỉ sử dụng củ sạc được khuyến nghị để sạc thiết bị. Trường hợp sử dụng củ sạc ngoài khuyến nghị có thể gây ảnh hưởng đến điều kiện bảo hành và gây nguy hiểm khi sử dụng. Nếu sản phẩm có kèm theo cáp sạc, vui lòng kết nối cáp sạc với củ sạc có chứng nhận CCC hoặc kết nối với máy tính để sạc thiết bị.</p> <p>Sau khi sạc đầy, tai nghe có thể sử dụng lên đến 21 giờ nghe nhạc, 15 giờ đàm thoại, hoặc 360 giờ chờ. Thời gian sử dụng này còn tùy thuộc vào điện thoại, cài đặt, cách sử dụng và môi trường người dùng.</p> <p style="text-align: center;">15</p>	<p>Xử lý sự cố</p> <table border="1"> <thead> <tr> <th>Vấn đề thường gặp</th> <th>Nguyên nhân</th> <th>Xử lý</th> </tr> </thead> <tbody> <tr> <td>Tai nghe không lên.</td> <td>Pin đã cạn. Nút gạt nguồn không đúng vị trí</td> <td>Sạc đầy pin cho tai nghe. Tắt và bật lại nút nguồn.</td> </tr> <tr> <td>Không sạc được tai nghe</td> <td>Chưa kết nối bộ sạc chắc chắn</td> <td>Kết nối với bộ sạc lại.</td> </tr> <tr> <td>Không tắt được tai nghe.</td> <td>Tai nghe bị lỗi phần mềm trong quá trình vận hành sai cách.</td> <td>Kết nối bộ sạc và reset lại tai nghe.</td> </tr> <tr> <td>Không tìm thấy tai nghe trong cài đặt kết nối</td> <td>Tai nghe chưa ở trạng thái chờ kết nối. Cài đặt kết nối của điện thoại bị lỗi</td> <td>Đưa tai nghe về trạng thái chờ kết nối. Khởi động lại điện thoại và thử lại lần nữa.</td> </tr> </tbody> </table> <p style="text-align: center;">16</p>	Vấn đề thường gặp	Nguyên nhân	Xử lý	Tai nghe không lên.	Pin đã cạn. Nút gạt nguồn không đúng vị trí	Sạc đầy pin cho tai nghe. Tắt và bật lại nút nguồn.	Không sạc được tai nghe	Chưa kết nối bộ sạc chắc chắn	Kết nối với bộ sạc lại.	Không tắt được tai nghe.	Tai nghe bị lỗi phần mềm trong quá trình vận hành sai cách.	Kết nối bộ sạc và reset lại tai nghe.	Không tìm thấy tai nghe trong cài đặt kết nối	Tai nghe chưa ở trạng thái chờ kết nối. Cài đặt kết nối của điện thoại bị lỗi	Đưa tai nghe về trạng thái chờ kết nối. Khởi động lại điện thoại và thử lại lần nữa.
Vấn đề thường gặp	Nguyên nhân	Xử lý																					
Tai nghe không lên.	Pin đã cạn. Nút gạt nguồn không đúng vị trí	Sạc đầy pin cho tai nghe. Tắt và bật lại nút nguồn.																					
Không sạc được tai nghe	Chưa kết nối bộ sạc chắc chắn	Kết nối với bộ sạc lại.																					
Không tắt được tai nghe.	Tai nghe bị lỗi phần mềm trong quá trình vận hành sai cách.	Kết nối bộ sạc và reset lại tai nghe.																					
Không tìm thấy tai nghe trong cài đặt kết nối	Tai nghe chưa ở trạng thái chờ kết nối. Cài đặt kết nối của điện thoại bị lỗi	Đưa tai nghe về trạng thái chờ kết nối. Khởi động lại điện thoại và thử lại lần nữa.																					

105双铜 单色双面印刷 风琴折60x90mm