

















front side
正面

 <p>HAVIT</p> <p>TW971 TRUE WIRELESS STEREO EARBUDS</p> <p>USER'S MANUAL</p>	<p>Product and accessories</p>  Earbuds *1  Charging Case *1  3 pairs of earcaps (L/M/S size)  Type-C Charging Cable *1  User manual *1	<p>Description of product structure</p>  <ol style="list-style-type: none"> MFB Microphone LED indicator Charging port <p>Wearing method</p>  <p>Gently insert the earbuds into the ear then adjust the appropriate comfort.</p>	<p>Basic function</p> <p>01 Power on, Bluetooth connection ---Follow the steps (Please confirm that your phone is built-in Bluetooth function) 1. Power on Method 1: While open the case, earbuds automatically connect. Method 2: Long press the left or right MFB for 5 seconds. 2.Turn on the earbuds that it enters the pairing state and select "HAVIT TW971" referring to your phone instructions.</p> <p>*Note: a). HAVIT TW971 remembers previously connected devices. When turned on, earbuds attempts to reconnect to previously connected devices. b). HAVIT TW971 will lose the connection when deviate the working range of Bluetooth. The earbuds will reconnect automatically if you come back to the range.</p> <p>02 Power off Method 1: If earbuds are outside the case, long</p>	<p>press the MFB for 5 seconds. Method 2: Put the earbuds into the charging case and close the charging case, they will automatically shut off.</p> <p>03 Answering incoming calls Short press the left or right MFB once to answer incoming calls.</p> <p>04 End the call Long press the left or right MFB to end the current call.</p> <p>05 Decline incoming calls Short press left or right MFB once to reject a call.</p> <p>06 Voice assistant Double-click the MFB to activate voice assistant.</p> <p>07 Music playing 1. Play/Pause: Short press the left or right MFB. 2.Long press the left MFB to switch to the previous song. 3. Long press the right MFB to switch to the</p>	<p>next song.</p> <p>08 Mono mode (take out any earbuds as a unilateral Bluetooth earbud) (note: single channel mode only needs to remove one of earbuds from the charging box; If two earbuds are removed before connection, the earbud will be used in TWS mode by default, and the TWS connection will be automatically realized.) 1.Take out a earbud from charging case, the earbud automatically turn on and reconnect to previously connected devices. 2.Switch from one earbud to the other when playing music, taking out the other earbud from the charging case and these two earbuds will connected automatically. Both earbuds will play music automatically and then put the earbud which do not need anymore into the charging case and the switching process completes. 3.Please refer to the TWS mode for more functions.</p> <p>09 Charging -Case Charge the case using the Type-C cable connected to a computer or wall charger. The</p>	<p>indicator of the charging case is white when charging. After fully charged, indicator turns solid white.</p> <p>-Earbuds 1.The earbuds indicator is white when in charging; 2.After fully charged, the earbuds indicator will be off.</p> <p>Specification Bluetooth Version: V5.3 Earbud Battery: 30mAh*2(Fully charged in 1.5H) Charging case battery:300mAh Play time:4-5H (60% volume) Talk time: 4H Charging time: About 1-2H Wireless working range: 10-15M (without obstacles) Speaker: 8MM*2</p>	<p>Warnings</p> <ol style="list-style-type: none"> Please follow the instruction to operate. Please charge the earbuds with input power below 5V/1A, in order to protect the battery. Please store or use the earbuds in a normal temperature environment. Please do not use this product near the water. Do not immerse this product in any liquid or splash any liquid on this product. Please keep the earbuds from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti high temperature. Don't jam the ports of the earbuds, such as charger port, LED port and microphone etc.. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the maximum level for a long time. Whatever reasons damage the earbuds, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service.
---	---	--	---	--	--	--	---

back side
反面

 <p>HAVIT</p> <p>TW971 TAI NGHE BLUETOOTH KHÔNG DÂY</p> <p>HƯỚNG DẪN SỬ DỤNG</p>	<p>Sản phẩm và phụ kiện</p>  Tai nghe *1  Hộp sạc *1  3 cặp nút bịt tai nghe (Size S/M/L)  Cáp sạc Type-C *1  Hướng dẫn sử dụng *1	<p>Cấu trúc sản phẩm</p>  <ol style="list-style-type: none"> Nút đa chức năng (MFB) Micrô Đèn báo LED Cổng sạc <p>Cách đeo tai nghe</p>  <p>Nhẹ nhàng nhét tai nghe vào tai sau đó điều chỉnh độ thoải mái cho phù hợp.</p>	<p>Chức năng cơ bản</p> <p>01 Bật nguồn, kết nối Bluetooth ---Làm theo các bước sau (Vui lòng đảm bảo điện thoại của bạn có hỗ trợ chức năng Bluetooth) 1. Bật nguồn Cách 1: Khi mở hộp sạc, tai nghe sẽ tự động kết nối. Cách 2: Nhấn và giữ nút MFB trái hoặc phải trong 5 giây. 2.Bật tai nghe ở trạng thái ghép nối và chọn "HAVIT TW971" theo hướng dẫn trên điện thoại của bạn.</p> <p>*Chú ý: a). HAVIT TW971 ghi nhớ các thiết bị đã kết nối trước đó. Khi bật nguồn, tai nghe sẽ kết nối lại với các thiết bị đã được kết nối trước đó. b). HAVIT TW971 sẽ ngắt kết nối nếu thiết bị nằm ngoài phạm vi hoạt động của Bluetooth. Tai nghe sẽ tự động kết nối lại nếu thiết bị nằm trong phạm vi hoạt động của Bluetooth.</p> <p>02 Tắt nguồn Cách 1: Nếu tai nghe nằm ngoài hộp sạc, hãy</p>	<p>nhấn và giữ nút MFB trong 5 giây. Cách 2: Đặt tai nghe vào hộp sạc và đóng lại, tai nghe sẽ tự động tắt.</p> <p>03 Trả lời cuộc gọi đến Bấm nhanh nút MFB trái hoặc phải một lần để trả lời các cuộc gọi đến.</p> <p>04 Kết thúc cuộc gọi Nhấn nhanh nút MFB bên trái hoặc bên phải một lần để kết thúc cuộc gọi.</p> <p>05 Từ chối cuộc gọi đến Nhấn và giữ nút MFB bên trái hoặc bên phải để kết từ chối cuộc gọi đến.</p> <p>06 Trợ lý giọng nói Nhấp đúp vào nút MFB để kích hoạt trợ lý giọng nói.</p> <p>07 Chơi nhạc 1. Phát/Tạm dừng: Nhấn nhanh nút MFB trái hoặc phải. 2. Nhấn và giữ nút MFB bên trái để chuyển sang bài hát trước đó. 3. Nhấn và giữ nút MFB bên phải để chuyển sang bài hát tiếp theo.</p>	<p>08 Chế độ đơn âm (lấy tai nghe bất kỳ ra làm tai nghe Bluetooth đơn) (Lưu ý: Chế độ một kênh chỉ cần tháo một trong hai tai nghe khỏi hộp sạc; Nếu tháo hai tai nghe trước khi kết nối, thì tai nghe sẽ được sử dụng ở chế độ TWS theo mặc định và kết nối TWS sẽ được tự động thực hiện.) 1.Lấy tai nghe ra khỏi hộp sạc, tai nghe sẽ tự động bật và kết nối lại với các thiết bị đã kết nối trước đó. 2.Chuyển từ tai nghe này sang tai nghe kia khi phát nhạc: lấy tai nghe còn lại ra khỏi hộp sạc, hai tai nghe sẽ tự động kết nối với nhau. Lúc này, cả hai tai nghe sẽ tự động phát nhạc, sau đó đặt tai nghe không cần dùng nữa vào hộp sạc, quá trình chuyển đổi hoàn tất. 3.Vui lòng tham khảo chế độ TWS để biết thêm các chức năng khác.</p> <p>09 Sạc tai nghe -Hộp sạc Sạc hộp sạc bằng cáp Type-C được kết nối với máy tính hoặc bộ sạc. Đèn báo của hộp sạc có màu trắng khi sạc. Sau khi được sạc đầy, đèn báo chuyển sang màu trắng đục.</p>	<p>-Tai nghe 1. Đèn báo tai nghe có màu trắng khi đang sạc; 2. Sau khi được sạc đầy, đèn báo tai nghe sẽ tắt.</p> <p>Thông số kỹ thuật Phiên bản Bluetooth: V5.3 Dung lượng pin tai nghe: 30mAh*2 (Sạc đầy trong 1.5 giờ) Dung lượng pin hộp sạc: 300mAh Thời gian chơi nhạc: 4-5 giờ (60% âm lượng) Thời gian đàm thoại: 4 giờ Thời gian sạc: Khoảng 1-2 giờ Phạm vi hoạt động không dây: 10-15m (không có chướng ngại vật) Loa: 8MM*2</p> <p>Cảnh báo 1. Vui lòng làm theo hướng dẫn để vận hành sản phẩm. 2. Vui lòng sạc tai nghe với nguồn điện đầu vào dưới 5V/1A để bảo vệ pin. 3. Vui lòng bảo quản hoặc sử dụng tai nghe trong môi trường có nhiệt độ bình thường. 4. Vui lòng không sử dụng sản phẩm này gần nước. Không nhúng sản phẩm này vào bất kỳ chất lỏng nào hoặc vẩy bất kỳ chất lỏng nào lên sản phẩm này.</p>	<ol style="list-style-type: none"> Vui lòng giữ tai nghe cách xa nguồn nhiệt, chẳng hạn như bộ tản nhiệt, bộ điều chỉnh không khí nóng, bếp lò hoặc các dụng cụ sinh nhiệt khác. Vì sản phẩm không chống nhiệt độ cao. Không làm kẹt các cổng của tai nghe, chẳng hạn như cổng sạc, cổng đèn LED và micrô, v.v. Để bảo vệ thính giác của bạn và kéo dài tuổi thọ của loa, không nên điều chỉnh âm lượng ở mức tối đa trong thời gian dài. Khi gặp sự cố làm hỏng tai nghe, vui lòng liên hệ với bộ phận CSKH của chúng tôi kịp thời thay vì tự sửa chữa để đảm bảo quyền lợi bảo hành.
--	--	---	--	---	--	--	--

材质: 128g双铜纸 双面印刷, 风琴折

印刷色号(Printing color number): C:0 M:0 Y:0 K:70

尺寸(Size): 55 X 77 mm