

材质: 80g双铜纸

尺寸: 75x75mm


## BLUETOOTH SPEAKER AVA+ Go Z12




User Manual

Thank you for purchasing Bluetooth Speaker AVA+ Go Z12.  
Please carefully read user guide in property and keep this for further reference.


### Packing list



1 pc speaker




1 pc Micro charging cable



1 pc user manual

### Key function direction

- ① Pause/Play/Mode Button
- ② Previous track/Volume down
- ③ Next track/Volume up
- ④ Light button



### Power On/Off

Power On: Move the button to "ON" to power it on, the speaker will sound "ting ting ting", the blue light flashes.  
Power off: Move the button to "OFF" to power it off, the blue light turn off.

### Key function direction

Short press "-" button when playing music, the player will play the last track;  
Long press "-" to decrease the volume continuously  
Short press "+" button when playing music, the player will play the next track;  
Long press "+" to increase the volume continuously

Short press "⏸/M" to pause/play music  
Press three times button "⏸/M": Bluetooth, FM mode, TF card.

Micro charging:  
1. Charging with a DC5V~1A USB power adapter  
2. When the speaker is fully charged, the red light will turn off.

### Bluetooth Connection

1. Start the speaker, there is a prompt tone, Bluetooth enters the pairing mode.
2. Turn on the mobile phone, turn on Bluetooth, search for the Bluetooth code name "AVA+ Go Z12" and click; after a few seconds, you will hear the prompt tone of successful pairing and connection, the mobile phone displays connected.
3. In subsequent use, as long as the device's bluetooth is turned on, it can be automatically connected.
4. Double press "⏸/M" to disconnect Bluetooth.

### Playing MP3 files from Micro SD:

1. Insert Micro SD card into TF Slot.
  2. Play, pause or skip a selected track using the controls on the speaker.
- FM mode:  
Press three time button "⏸/M" into FM mode, short press this button to search station automatically, press again to stop searching. Then, short press "+", "-" to choose the FM station.  
Note: In the FM mode, need in charging cable increase the FM radio signal

TWS function: While at the same time open two devices and dont connect in the bluetooth mode, long press "⏸/M" button of either of the speaker and then, you will hear the prompt tone of successful pairing and connection. You search for the Bluetooth code name "AVA+ Go Z12" and click to use this function.

### Attentions:

1. Do not use abrasive cleaners to clean this product.
2. Do not allow this product to be heated, close to fire source or direct sunlight for a long time. It will easy to burn and damage the electronic components.
3. Do not attempt to disassemble this product to make any modifications.
4. Do not use this product in the rain.
5. If you do not plan to use this product for a long time, please store it in a dry environment and charge the speaker at least once a month to prolong its life and avoid extreme temperatures and dust.
6. If you saw smoke coming out of the machine or other improper phenomenon, please contact the retailer to solve the issue immediately.
7. Do not throw the machine.

Note!  
In order to improve product performance, our products are constantly updated. It is no additional notice about technical issues and this manual is for reference only, please forgive.  
Thank you for your purchase.


## LOA BLUETOOTH AVA+ Go Z12




Hướng dẫn sử dụng

Cảm ơn bạn đã lựa chọn Loa Bluetooth AVA+ Go Z12. Vui lòng đọc kỹ hướng dẫn để sử dụng đúng cách và giữ lại để tham khảo thêm.

### Bộ sản phẩm gồm



1 loa bluetooth



1 dây sạc loa Micro



1 hướng dẫn sử dụng

### Chức năng các phím

- ① Phát nhạc/ tạm dừng/ Chuyển chế độ kết nối
- ② Phát bài nhạc trước đó /Giảm âm lượng
- ③ Phát bài nhạc tiếp theo/Tăng âm lượng
- ④ Nút điều chỉnh chế độ đèn



### Bật / tắt nguồn

Bật nguồn: Di chuyển nút qua chữ "ON" để bật nguồn, đèn màu xanh gần khe cắm sạc sẽ nhấp nháy.  
Tắt nguồn: Di chuyển nút qua chữ "OFF" để tắt nguồn, đèn màu xanh dưới khe cắm sạc sẽ tắt.

### Tính năng phím

Nhấn nhanh nút "-" khi phát nhạc, loa sẽ phát lại bài hát trước đó.  
Nhấn và giữ "-" để giảm âm lượng.  
Nhấn nhanh nút "+" khi phát nhạc, loa sẽ phát bài hát tiếp theo.  
Nhấn và giữ "+" để tăng âm lượng liên tục.

Nhấn nhanh nút "⏸/M" để tạm dừng hoặc phát nhạc  
Nhấn 3 lần "⏸/M" để đổi chế độ kết nối: Bluetooth, FM, thẻ TF card

Sạc Micro:  
1. Sạc loa bằng bộ chuyển đổi USB DC-5V ~ 1A  
2. Khi loa được sạc đầy, đèn màu đỏ sẽ tắt.

### Kết nối Bluetooth

1. Khởi động loa, có âm báo nhắc, Bluetooth chuyển sang chế độ chờ ghép nối.
2. Bật điện thoại di động, bật Bluetooth, tìm kiếm tên Bluetooth "AVA+ Go Z12" và nhấp vào; sau vài giây, bạn sẽ nghe thấy âm báo nhắc ghép nối và kết nối thành công, điện thoại di động hiển thị được kết nối.
3. Trong lần sử dụng tiếp theo, Loa có thể tự động kết nối khi Bluetooth của thiết bị mà được kết nối gần nhất đang mở.
4. Nhấn 2 lần nút "⏸/M" để ngắt kết nối Bluetooth.

### Phát nhạc MP3 từ Micro SD:

1. Cắm thẻ Micro SD vào khe cắm TF.
  2. Phát, tạm dừng hoặc bỏ qua bản nhạc đã chọn bằng các nút điều khiển trên loa.
- Chế độ FM:  
Nhấn 3 lần nút "⏸/M" để vào chế độ FM, nhấn nhanh nút này để tự động tìm đài phát, nhấn lần nữa để dừng tìm kiếm. Sau đó, ấn nhanh nút "+", "-" để chọn kênh FM.  
Ghi chú: Ở chế độ FM, cần cắm cáp sạc để tăng tín hiệu đài FM.

Kết nối hai loa: Mở nguồn hai loa cùng một thời gian và ở trạng thái không kết nối bluetooth, nhấn và giữ nút "⏸/M" của 1 trong 2 loa để có thể kết nối hai loa với nhau. Bạn sẽ nghe tiếng báo hiệu cho sự kết nối thành công và sau đó tìm ở thiết bị kết nối Bluetooth với tên "AVA+ GO Z12" và nhấn vào để sử dụng chức năng này.

### Chú ý:

1. Không sử dụng chất tẩy rửa mài mòn để làm sạch sản phẩm.
2. Không để Loa bị làm nóng, gần nguồn lửa hoặc tiếp xúc trực tiếp với ánh nắng mặt trời trong thời gian dài, nó sẽ dễ làm cháy và hỏng các linh kiện điện tử.
3. Không cố gắng tháo rời sản phẩm này để thực hiện bất kỳ sửa đổi nào.
4. Không sử dụng sản phẩm này dưới trời mưa.
5. Nếu bạn không định sử dụng sản phẩm này trong một thời gian dài, vui lòng bảo quản nó ở nơi khô ráo và sạc loa ít nhất mỗi tháng một lần để kéo dài tuổi thọ của loa cũng như tránh nhiệt độ quá cao và bụi.
6. Nếu nhìn thấy khói bốc ra từ máy hoặc hiện tượng bất thường khác vui lòng liên hệ với nhà bán lẻ để giải quyết vấn đề ngay lập tức.
7. Không tác động mạnh hay để vật nặng lên loa.

Ghi chú!  
Để nâng cao hiệu suất của sản phẩm, sản phẩm của chúng tôi được cập nhật liên tục. Nội dung có thể thay đổi mà không báo trước và sách hướng dẫn này chỉ mang tính chất tham khảo, mong bạn thứ lỗi. Cảm ơn bạn vì đã mua hàng.