



THONET & VANDER® | KURBIS™ cinema 2.0 speakers
QUICK GUIDE

_01 SYSTEM INSTALLATION


A.




B.




C.



Double RCA Stereo Auxiliary Cable (not included)




RCA Stereo to 3.5 mm Stereo Auxiliary Cable (included)



D.



Optical Cable (not included)




E.



Power Cable (included)

F.






_02 BLUETOOTH® PAIRING

Switch on the speaker. A blue light will start blinking, this means the speaker is in pairing mode. Turn on Bluetooth® on your device (smartphone, tablet, PC, etc.) and select KÜRBIStm to pair the speaker. The light will stop blinking once the connection is established. If pairing fails, try again. If you require further support, please send an e-mail to support@thonet-vander.com. For switching from any other mode to Bluetooth® mode, press the INPUT button [3] repeatedly on your remote control until the led turns blue or go to the Speaker Side Panel and press the Volume button [B].

_03 VOLUME CONTROL | From Side Panel

- A_** Mode LED on
- B_** Digital Volume Control / Mode button
(Switch Bluetooth®, Optical, Aux mode)
- C_** Adjust treble or high frequencies
- D_** Adjust bass or low frequencies



_04 REMOTE CONTROL

REMOTE CONTROL

- 1_** Stand by mode
- 2_** Mute
- 3_** Input selection
- 4_** Previous Track
- 5_** Play/Pause
- 6_** Next Track
- 7_** Increase Volume
- 8_** Decrease Volume

LED ACTION [A]

on Side Panel

- 1_** Steady red light
- 3_** Blue light: Bluetooth®
- Orange light: Optical
- Green light: Auxiliary
- White light: RCA

_04 ACCESORIES | Our KÜRBIS™ cinema 2.0 speakers include:

- _ Remote Control
 - _ RCA Stereo to 3.5 mm Stereo Auxiliary Cable
 - _ Transparent cable for connecting passive speaker
 - _ Power cable (plug IEC 60320 C7)* or power cable with ground tab (plug IEC 60320 C7)* or UK (plug BS 1363)*
- (*) according to country