T

User Manual



True Wireless Earbuds

Model NO.: FreeGo Y70

Thank you for purchasing your new Y70 ture wireless earbuds.

We recommend that you spend some time reading this instruction manual in order to fully understand all the operational features it offers.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

Safety Rules

1. Charge the earbuds and the charging case at least once every 6 months.
2. Do not store the product in extreme temperature (below 0℃ or above 45℃)
3. Do not use chemicals or detergents to clean the product.
4. Do not drop or knock the product on hard surfaces.
5. Do not scrape the surface of product with sharp objects.
6. Do not try to take the product apart.

In the Box

- Wireless Earbuds
- Portable Charging Case
- Type-C Charging Cable
- User manual
- Ear-Tips x 3 (S/M/L)

Product Overview



1. LED indicator
2. Touch Area
3. Microphone
4. Silicone Ear-tips
5. Earphones Charging Contacts
6. Real-time battery display

Find Your Fit

1. Choose the size of silicone ear-tips that you feel the most comfortable with.
2. Gently insert the earbuds into ears and adjust to an appropriate angle for comfortable fit.
   Tips: Choosing the right ear-tips will give you a better sound quality experience.

Specification

Bluetooth version	V5.4
BT profiles support	HSP, HFP, A2DP, AVRCP
Bluetooth range	10 m / 33 ft
Frequency response	20 Hz - 20 KHz
Battery capacity	40mAh for each earbuds 300mAh for charging case
Charging time	Around 1.5 hours
Playing time	6-8 hours
Talk time	Around 3 hours
Speaker Driver	φ13mm
Earbuds weight	4.3g each
Case weight	29g

Power ON/OFF

Power ON

1. Open the charging case, take out the earbuds, they will power on automatically.
2. Long press left and right earbuds for 3 seconds, the earbuds will power on.

Power OFF

1. Put the earbuds into the charging case, the earbuds will power off automatically.
2. Long press left and right earbuds for 5 seconds, the earbuds will power off.

Remark: Earbuds power off when they stay out of range for over 3 minutes.

Charging

1. Fully charge both the earbuds and the charging case before the first use.
2. To prevent damage, use the provided USB-C cable.
3. Fully dry off the earbuds and the USB port before charging.
4. Charging takes around 1.5 hours.

LED Indications

Pairing

1. When using Y70 True Wireless Earbuds the first time. Take the earbuds out the charging case one earbuds indicator white and red light breathing slow flash another indicator off the "pairing mode" is on.
2. Turn on Bluetooth on your device.
3. Search and select "AVA+ FREEGO Y70"
4. When connected, the earbuds indicators light off.

Multi Functions

Function	Left earbud	Right earbud
Play/Pause End a call	Double tap	Double tap
Next song		Long touch for 2s
Previous song	Long touch for 2s	
Volume up		Single tap
Volume down	Single tap	
Answer a call	Single tap	Single tap
Reject a call	Long touch for 2s	Long touch for 2s
Active Siri/ Google Assistant	Triple tap	Triple tap
Game mode/ Music mode	Tap 4 times	Tap 4 times

Factory reset

1. Take out the earbuds from the charging case, ensure both earbuds disconnect with any device.
2. Quickly press either one of the earbuds 5 times and its LED light will flash 3 times.
3. Place both the earbuds inside the charging case and repeat the pairing process.

WARNING

1. Listening to earbuds at high volume levels, particularly over extended periods of time, may damage your hearing.
2. Supervise children when using equipment. This product is not a toy.
3. The small parts included with this product can be a choking hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age.

MADE IN CHINA

Hướng dẫn sử dụng

Tai nghe không dây

Model NO.: FreeGo Y70

Đọc tất cả hướng dẫn sử dụng an toàn trước khi sử dụng.

Quy tắc an toàn

1. Sạc tai nghe và hộp sạc ít nhất 6 tháng một lần.
2. Không bảo quản sản phẩm ở nhiệt độ quá cao (dưới 0℃ hoặc trên 45℃)
3. Không sử dụng hóa chất, chất tẩy rửa để vệ sinh sản phẩm.
4. Không làm rơi hoặc va đập sản phẩm trên bề mặt cứng.
5. Không cạo bề mặt sản phẩm bằng các vật sắc nhọn.
6. Không cố tháo rời sản phẩm.

Bên trong hộp

- Tai nghe không dây
- Hộp sạc
- Cáp sạc Type-C
- Hướng dẫn sử dụng
- Đệm tai thay thế x 3 (S/M/L)

Tổng quan sản phẩm



1. Đèn LED tai nghe
2. Vùng cảm ứng
3. Micro
4. Đệm tai
5. Điểm tiếp xúc sạc tai nghe
6. Màn hình hiển thị pin

Cách đeo phù hợp

1. Chọn kích cỡ đệm tai mà bạn cảm thấy thoải mái nhất.
2. Nhẹ nhàng đeo tai nghe vào tai và điều chỉnh theo một góc thích hợp để vừa vận thoải mái.



Thông số kỹ thuật

Phiên bản Bluetooth	V5.4
Cấu hình Bluetooth	HSP, HFP, A2DP, AVRCP
Phạm vi Bluetooth	10 m / 33 ft
Tần số	20 Hz - 20 KHz
Dung lượng pin	Tai nghe: 40mAh*2 Hộp sạc: 300mAh
Thời gian sạc	Khoảng 1.5 giờ
Thời gian sử dụng	Khoảng 6-8 giờ
Thời gian đàm thoại	Khoảng 3 giờ
Màng loa	φ13mm
Trọng lượng tai nghe	4.3g*2
Trọng lượng hộp sạc	29g

Bật/ Tắt nguồn

Bật nguồn

1. Mở hộp sạc, lấy 2 tai nghe ra, tai nghe sẽ tự động bật nguồn.
2. Nhấn và giữ tai nghe bên trái và bên phải trong 3 giây, tai nghe sẽ bật nguồn.

Tắt nguồn

1. Đặt 2 tai nghe vào hộp sạc, tai nghe sẽ tự động tắt nguồn.
2. Nhấn và giữ tai nghe bên trái và bên phải trong 5 giây, tai nghe sẽ tắt nguồn.

Lưu ý: Tai nghe sẽ tắt nguồn khi nằm ngoài phạm vi Bluetooth trong hơn 3 phút.

Sạc pin

1. Sạc đầy cả tai nghe và hộp sạc trước lần sử dụng đầu tiên.
2. Để tránh hư hỏng, hãy sử dụng cáp USB-C đi kèm.
3. Lau khô hoàn toàn điểm tiếp xúc sạc của tai nghe và cổng sạc của hộp sạc trước khi sạc.
4. Quá trình sạc mất khoảng 1.5 giờ.

Trạng thái đèn LED

Kết nối

1. Khi lần đầu sử dụng tai nghe TWS Y70. Lấy hai tai nghe ra khỏi hộp sạc, một bên tai nghe sẽ nhấp nháy đèn trắng và đỏ luân phiên, tai nghe còn lại đèn tắt cho biết đang trong trạng thái chờ ghép nối.
2. Bật Bluetooth trên thiết bị của bạn.
3. Tìm kiếm và chọn "AVA+ FREEGO Y70".
4. Khi được kết nối thành công, đèn báo trên tai nghe sẽ tắt.

Đa chức năng

Chức năng	Tai nghe bên trái	Tai nghe bên phải
Chơi/dừng nhạc Kết thúc cuộc gọi	Chạm 2 lần	Chạm 2 lần
Bài hát tiếp theo		Chạm và giữ 2 giây
Bài hát trước đó	Chạm và giữ 2 giây	
Tăng âm lượng		Chạm 1 lần
Giảm âm lượng	Chạm 1 lần	
Trả lời cuộc gọi	Chạm 1 lần	Chạm 1 lần
Từ chối cuộc gọi	Chạm và giữ 2 giây	Chạm và giữ 2 giây
Trợ lý ảo	Chạm 3 lần	Chạm 3 lần
Chế độ chơi game/nghe nhạc	Chạm 4 lần	Chạm 4 lần

Cài đặt gốc

1. Lấy tai nghe ra khỏi hộp sạc, đảm bảo cả hai tai nghe đều ngắt kết nối với thiết bị.
2. Chạm nhanh một trong hai tai nghe 5 lần và đèn LED sẽ sáng nhấp nháy 3 lần.
3. Đặt cả hai tai nghe vào hộp sạc và lập lại quá trình ghép nối.

Cảnh báo

1. Không nên nghe tai nghe ở mức âm lượng lớn trong thời gian dài, vì có thể làm hỏng thính giác của bạn.
2. Giám sát trẻ em khi sử dụng thiết bị. Các bộ phận nhỏ đi kèm với sản phẩm này có thể gây nguy cơ nghẹt thở. Sản phẩm này không dành cho trẻ nhỏ sử dụng và để xa tầm tay trẻ em dưới 3 tuổi.

MADE IN CHINA