


# User Manual of SKMEI Model 1450


## A. Features

- 6 Digits LCD Display, Display Hour ,Minute ,Second ,Week
- Chime hourly and Daily Alarm
- 12 / 24H format selectable, Auto Calendar
- 1/100 second Chronograph with split function
- EL backlight



## B. Operational Manual


- At any mode, press A key then EL backlight will last for 3s.
- In normal Mode, Press D key to check Month and Date
- In normal Mode, Press C key to check Alarm time
- Press B key to convert mode:



### Chronograph function

In normal display mode: press B key , enter Chronograph mode

- Press D to start, press D again to suspend, press D again to continue,press D to suspend again,.....when suspend,press C key back to 0:00:00.
- In Chronograph mode, press D key to start, press C key enter into split function and get the first group record ,but the second group is still processing in the back ground, press C key again to run the third group record, press C again to stop the running of the second group and read the second record; but the third group is still processing in the back ground.....when the final group finished, Press D key to stop the SPL function, press C key to read the final group(SUM) record, press C key again to clear the record to 0:00:00.



### Alarm Setting

- in normal display Mode, press B key twice enter into Alarm Mode, and Alarm Hour is flashing,Press D key to adjust the correct hour for your Alarm.
- Press C key and the Alarm Minutes is flashing. Press D key to adjust the correct minute for your alarm.
- Press B key to exit.

### Alarm & Chime ON/OFF

- In normal display mode press C and D key together to ON/OFF the alarm.
- If the icon “🔔” appears in the corner, the alarm is ON. If the icon disappears, the alarm is OFF. Press B key to exit.
- In normal display mode, Hold C then press B key to ON/OFF the hourly chime.
- If all the week icons (MO/TU/WE/TH/FR/SA/SU) appear, the Chime is on; if all the week icons disappear, the Chime is off.

### Time Setting

In normal display Mode, press B key three times to enter time setting mode and the Seconds will be flashing.

Press D key to reset the Seconds to zero.

- Press C key the Minute will flash. Press D key to adjust the correct Minutes.
- Press C key the Hours will flash. Press D key to adjust correct Hours

- Press C key the Date will flash. Press D key to adjust correct Date
- Press C key the Month will flash. Press D key to adjust correct Month
- Press C key the Week will flash. Press D key to adjust the correct Week.
- Press B key to exit.