

# LM-TF005

## USER'S GUIDE

# USER'S GUIDE

LM-TF005( Seconds Cartoon, Multifunction Sport Watch )



**EL Backlight**



**Stopwatch**



**Dual Time**



**Countdown Timer**



**100 Year Calendar**



**5 Alarms**



**Pacer**



**Chime**




**100M Water Resistant**



**Battery(CR2025)**

## BUTTONS

- Button operation are indicated using the letters shown in the illustration.




- A -- Reset  
B -- Mode  
C -- EL backlight / -  
D -- Start / Stop / +

## ATTENTION

1. Never try to open the case or remove its back cover.
2. Do not operate buttons underwater.
3. Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
4. Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
5. Avoid exposing the watch to temperature extremes.
6. Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
7. Avoid to wear the watch in electromagnetic, static conditions.

## DISPLAY

- The screen shown in below:



## BACKLIGHT

- The backlight that uses an EL (electroluminescent) cause the display to glow for easy reading in the dark.

### Use EL Backlight

- In the timekeeping mode, press "C" to illuminate the display about 3 seconds.



# LARMES

---

# TRANSFORMERS

## MODE SELECTION

- Press "B" to change mode to mode in the following sequence:  
Timekeeping Mode → Stopwatch Mode → Countdown Mode → Alarm Mode → Dual Time Mode → Pacer Mode.

### a TIMEKEEPING

- 12/24H Format;
- Hour, Minutes, Seconds, Day of week, Month, Date;
- 100 years Calendar (2000 ~ 2099).



### b STOPWATCH

- 1/100 second unit;
- Measuring range: 0'00"00 ~ 23:59'59".




### c COUNTDOWN

- Countdown range: 23:59'59" ~ 0'00"00.



### d ALARM

- 5 Alarms;
- Hourly time signal;
- The alarm sounds at the preset time each day.



### e DUAL TIME

- The time for other time zone.



### f PACER

- 10 tempo.



## a TIMEKEEPING

### Time Setting

1. In the timekeeping mode, press "A" the seconds to flash(fashing indicated in set mode);



2. Press "D" to reset the seconds;



3. Press "B" change to the next selection;



4. Press "D" to increase the number, press and hold to change at high speed;



5. Repeat step 3 and 4, the selection in the following sequence:  
Seconds - Hour - Minutes - Year - Month - Date;

6. Press "A" to exit the set state, after you set (The day of week is auto displayed in accordance with year, month and date setting).

### 12/24H Format

- In the timekeeping mode, press "D" to switch between 12/24H formats.

