

PHILIPS

RO Dispenser

ADD6901



User Manual
Hướng Dẫn Sử Dụng

CONTENTS

1	Important notes	01
---	-----------------	----

2	Product specifications	03
---	------------------------	----

3	Product overview	03
---	------------------	----

4	User interface	04
---	----------------	----

5	Installation	04
---	--------------	----

6	Usage instructions	05
---	--------------------	----

7	Daily maintenance	08
---	-------------------	----

8	Filter replacement	09
---	--------------------	----

9	Error codes	10
---	-------------	----

10	Troubleshooting	11
----	-----------------	----

11	Packing list	12
----	--------------	----

12	Guarantee and support	12
----	-----------------------	----

1. Important notes

Note: All contents of this part relate to safety. The dangers, harmfulness, and potential accidents are explained herein. All users must strictly follow the instructions.


- Misuse may cause injury.
- The heating element surface is subject to residual heat after use.
- This appliance is intended for household and indoor use only.
- Do not immerse the appliance in any liquid.
- Do not use accessories which are not authorised by the manufacturer. The warranty will terminate automatically if machine failure is caused by unauthorised accessories.
- Please check for machine damages and verify all parts are included after unpacking.
- Keep the plastic bag or film away from babies and children to avoid suffocation.
- Use municipal tap water or filtered water as the water source.
- Please do not pour unknown liquids, water from sources of unknown quality or other extraneous materials of any sort into the tap water tank and filtered water tank.
- Please handle the machine with care to avoid injuries or damages resulting from dropping the appliance.
- Place the machine out of reach of children and pets.
- Children and persons incapable of operating the machine safely should use the machine under the supervision of a guardian.
- Place the machine in a cool and dry place, away from direct sunlight. Do not place it near any form of heat source.
- The machine shall not be placed in an environment that may have inflammable gas leakage.
- To avoid electric shock, do not touch the power plug with wet hands.
- To avoid damage, do not disassemble or modify the machine, or put any heavy objects on it.
- If the dispenser will not be used for a long time, please make sure it is disconnected from the power supply, and empty the tap water tank and filtered water tank.
- The inlet water temperature should be 5°C-38°C. If the temperature is higher than 38°C, the filter cartridge will be damaged and be unable to work. If the temperature is lower than 5°C, the dispenser might be frozen and the elements of the dispenser will be damaged.
- The dispenser can only be installed and used indoors, and with a power supply of reliable grounding.
- For first time use, or if the machine hasn't been used for a long time, fill the tap water tank and discard all the filtered water. Repeat this twice.
- Always use certified elements and accessories for the repairment and maintenance of the dispenser.

- Organic solvents such as gasoline shall not be used for wiping the housing of the dispenser. If cleaning is required, please gently wipe the surface of the product with a wet cloth after it is disconnected from power supply.
- If there is any abnormality, unplug the product from the power supply immediately, and do not leave the defective dispenser in working mode.
- With an upgrade of the product certain words or pictures on the manual may be different from the actual product, and the actual product shall govern in this case.
- If the user intends to extract ambient water or water of 45°C immediately after extracting hot water, some hot water may come out at the beginning, if so please watch out to avoid being burnt by the hot water. It is recommended to extract ambient water for 10 seconds to cool down the heating element.
- If the power cord appears to be damaged, please stop using the product. To avoid risks of danger, the power cord must be replaced by personnel authorised by the manufacturer.
- Do not disassemble or repair it the dispenser by yourself, nor hand it over to any person not authorized to repair, as improper repairing may cause risks of danger.
- The manufacturer will not bear responsibility for any consequences that are the results of failure to operate the appliance in accordance with the above guidelines.

2. Product specifications


Product name	Philips RO water dispenser
Model	ADD6901HWH01/ADD6901HBK01
Rated voltage	220V-240V~
Total rated power	2000W-2400W
Water heating capacity	20L/h, $\geq 90^{\circ}\text{C}$ (Max.95°C)
Filtration capacity	2000L
Water filtration flow rate	0.13L/min
Applicable water source	Municipal tap water or filtered water
Inlet water pressure	0 - 0.06MPa
Applicable water temperature	5-38°C

3. Product overview



Note: Illustration image is for reference only.

4. User interface





There could be a temperature deviation of $\pm 3^{\circ}\text{C}$ and a volume deviation of $\pm 10\%$, the actual temperature and volume depends on usage environment and local tap water quality.

5. Installation


Setup

- Place the machine on a cool and stable surface with good ventilation, and far away from any heat source.
- Remove the tap water tank lid and lift the tank upwards; fill the tap water tank with tap water and place it back the machine, then place the lid back to the tap water tank properly.
- Plug the power cord into a power socket, the machine will make sounds then the display panel will light up, indicating that the machine is working.



First time use


- During first time use, please check if any water leaks from or gathers around the dispenser, if there is any strange noise, burnt smell or smoke coming out from the product, please disconnect the power cord and contact customer services.
- For first time use, in order to ensure the best filtration performance, fill the tap water tank and discard all the filtered water. You may press and hold “  +  ” for 3 seconds to empty the tank and pipes when filtration is completed. Repeat this until two tanks of tap water are filtered.
- For first time use, in order to avoid dry-heating and protect the machine, please extract some ambient water before extracting hot water.



6. Usage instructions


Safety lock

- Safety lock and temperature memory mode: The machine will memorize the last selected water temperature, unlocking is required and press “  ” before extraction of hot water. The machine will be locked automatically if no keys are pressed within 10 seconds. Press the safety lock key for 10 seconds to disable the safety lock and temperature memory. The machine returns to “Ambient” after water extraction if the safety lock is disabled. Press the safety lock key for 10 seconds to enable the safety lock and temperature memory again.




Rinsing

- The dispenser will do auto rinsing before and after water filtration once it is connected with the power supply and the water tank is covered.
- Forced rinsing: long press “  +  ” for 3 seconds and the dispenser will rinse for 1 minute.




Water filtration

- If the built-in filtered water tank is at a low water level, the dispenser will automatically start to filter the tap water until the filtration is done. In the state of water filtration, the water filtration indicator is always on, and when the filtered water tank is short of water, changing water and water filtration indicator flash.




Water temperature adjustment

- Water temperature presets: there are four water temperature presets for selection: " Ambient " " 45°C " " 85°C " and " 95°C " .



Water volume adjustment


- Water volume presets: There are four water volume presets for selection: " 150ml " " 200ml " " 300ml " and " 500ml " .



Water extraction

- Select the water temperature and volume, and the display screen will display the selected water temperature. After pressing the safety lock (ambient water is automatically unlocked), press the water extraction button to extract purified water with the corresponding temperature and volume. You can press any button to stop during the extraction process.

Note: When extracting hot water, do not place your hand under the nozzle to avoid scalding.




Changing water

When the indicator of “” flashes, the water in the tap water tank needs to be changed, which will happen in the following conditions:

- Water in the tap water tank is at or less than the lowest water level;
- The TDS value of the tap water is too high.


To change the water in the tap water tank, open the lid of the tap water tank, lift the tap water tank upward and discard the drain water, fill the tap water tank with tap water, place it back to the machine and close the lid properly.

Note: Do not add water into the tap water tank without discarding the drain water.



Winter mode

- When the tap water temperature is lower than 10°C, winter mode can be set.
- Long press the ambient button for 3 seconds, and then press the water extraction button to extract 25°C filtered water. This is valid for a single operation only.




Sleep mode

- If there is no operation within 1 minute, the dispenser will automatically go to sleep mode.
- When the dispenser is in sleep mode, only the safety lock indicator is on, and all other indicators are off.
- Touch any button to end the sleep mode.

Emptying the tank and pipes

- Long press "85°C" button and "300ml" button for 3 seconds, the dispenser will extract water until the filtered water tank and the inner pipes are empty.

Note: In order to avoid dry-heating, if the tank and pipes have been emptied, please extract some ambient water before extracting hot water.




7. Daily maintenance

If the product is not used for over two days, it is suggested to change the water in the tap water tank and then empty the tank and pipes twice.

If the dispenser will not be used for over one week, please use one-key emptying to empty the water tank and disconnect the dispenser from the power supply. Seal the filter cartridge and store it in the refrigerator (2-5°C, do not put it into the freezer). When you use it again, please follow the cleaning procedures for first time use.

Tap water tank descaling

- It is recommended to descale the tap water tank every month to avoid scale build-up in the tap water tank.
- Descaling procedure: fill the tap water tank to half-way and add 30g of citric acid. Stir lightly then soak for 2 hours (do not place the tap water tank back to the dispenser). Then discard the citric acid solution and clean the entire water tank with tap water.



* Please purchase the cleaning brush and citric acid separately.

8. Filter replacement

Please change the filter cartridges according to the filter lifetime indicator on the display panel, or the suggested replacement cycle. New filter cartridge can be purchased from authorized retailers and service centers. The model is ADD541.


Name	RO Filter
Model	ADD541
Suggested Replacement Cycle	The machine automatically detects 1 year or 2000 liters of rated water volume
* Only the original Philips filter cartridge can be used.	

Filter lifetime indicator

- The color of the filter lifetime indicator shows the remaining lifetime of the filter cartridge:
 - Blue light: more than 10% lifetime left;
 - Flashing red light: less than 10% lifetime left;
 - Constant red light: less than 7-day lifetime left and please replace the filter now.


Filter cartridge replacement instructions

- Power off.
- Take out the tap water tank and then the machine's top lid.
- Rotate the used filter cartridge counterclockwise to the unlock "🔓" position and take it out.
- Insert the new filter cartridge into the dispenser. Rotate it clockwise to the lock "🔒" position and cover the machine's top lid; put the tap water tank back to the dispenser.
- Reset the filter cartridge lifetime and follow the cleaning procedures for first time use.



Reset the filter lifetime

- Long press "Ambient" + "150ml" for 3 seconds to reset the filter cartridge lifetime. There will be 3 beeps. The indicator light changes to blue again, and this means the filter lifetime has been reset successfully.



9. Error codes

E1: Tap water temperature sensor abnormality

Solutions: Check the tap water tank, discard the water if the water temperature exceeds 55 °C; put the tap water tank back to the machine. Please contact customer services if the problem cannot be solved.

E2: Outlet water temperature sensor abnormality

Solutions: Extract 300ml of ambient water. Please contact customer services if the problem cannot be solved.

E4: Heating element temperature sensor abnormality

Solutions: Stop using the dispenser or extract 300ml of ambient water, let the heating element to cool down to normal temperature and then extract hot water. Please contact customer services if the problem cannot be solved.

E6: Water filtration abnormality

Solutions: Turn off the power for 1-2 minutes, check whether the filter cartridge is installed properly and then reconnect the power. Please contact customer services if the problem cannot be solved.

EU: Display panel malfunction

Solutions: Please contact customer services.

10. Troubleshooting

Error	Causes	Solutions
Cannot extract ambient water	The product is not connected with the power supply.	Check if the dispenser is well connected with power supply.
	Button is not pressed properly.	Press the water extraction button again.
Cannot extract hot water	The dispenser is dry-heating.	Extract ambient water for several times, and then extract hot water.
	The water in the filtered water tank is at low level.	Wait for a while till the water filtration indicator stops flashing.
Cannot filter water	Filter cartridge is not installed properly.	Disconnect the dispenser from the power supply. Open the machine's top lid and take out the filter cartridge, then install it properly.
	The water in the tap water tank is at low water level.	Take out the tap water tank and change water.
	The tap water tank is not installed properly.	Check the tap water tank and install it properly.
Strange noise when filtering	The quality of the tap water does not meet the requirement and the filter cartridge is blocked earlier than expected.	Change the filter cartridge and check it again.
Water leakage	The removable drip tray is full.	Empty the removable drip tray.
	The check valve on tap water tank base is blocked or in the wrong position.	Put the check valve back to the original position or contact customer services.
	The sealing valve at the bottom of the tap water tank is blocked.	Remove the blockage.
	Water oozes from the dispenser.	Empty the tap water tank and filtered water tank, power off, then contact customer services.
Odd taste of the water	The new dispenser hasn't been cleaned.	Follow the cleaning procedures for first time use.
	The dispenser has not been used for a long time.	Follow the cleaning procedures for first time use.
	Filter cartridge is not changed as required.	Change the filter cartridge.

Leakage of electricity	Bad grounding.	Three-core plug with reliable grounding must be used.
	The power cord is damaged.	Please contact customer services.
Button/display panel does not respond	Damaged parts.	Please contact customer services.
	The system halts.	Disconnect the dispenser from power supply for 1-2 minutes and then plug it in again.

11. Packing list

Dispenser	1x
Removable drip tray	1x
User manual	1x
Usage Guide and Precautions	1x

12. Guarantee and support

If you need information or have any questions, please visit www.philips.com/support or contact the consumer service center in your country/region. If there is no consumer service center in your country/region, please contact your local distributor.

Within two years from the date of purchase, you will receive free warranty service for any damage caused by manufacturing process problems, or any damage to components under normal use conditions confirmed by our maintenance service personnel.

Warranty service excludes frequently replaced consumables, auxiliary equipment, shipping costs and door-to-door service. Please show proof of purchase to service personnel when servicing.

Please keep this user manual for future reference.

Nội dung

1	Ghi chú quan trọng	14
---	--------------------	----

2	Thông số kỹ thuật	16
---	-------------------	----

3	Thông số sản phẩm	16
---	-------------------	----

4	Giao diện người dùng	17
---	----------------------	----

5	Lắp đặt	17
---	---------	----

6	Hướng dẫn sử dụng	18
---	-------------------	----

7	Bảo trì định kỳ	21
---	-----------------	----

8	Thay thế lõi lọc	22
---	------------------	----

9	Mã lỗi	23
---	--------	----

10	Xử lý sự cố	24
----	-------------	----

11	Danh sách đóng gói	25
----	--------------------	----

12	Bảo hành và dịch vụ	25
----	---------------------	----

1. Ghi chú quan trọng

Ghi chú: Tất cả nội dung của phần này liên quan đến an toàn. Những nguy hiểm, tác hại và tai nạn tiềm ẩn được giải thích ở đây. Tất cả người dùng phải tuân thủ nghiêm ngặt các hướng dẫn.


- Sử dụng sai có thể gây nguy hiểm.
- Bề mặt bộ phận làm nóng có thể chịu nhiệt dư sau khi sử dụng.
- Thiết bị này chỉ được thiết kế để sử dụng cho hộ gia đình và trong nhà.
- Không nhúng thiết bị vào bất kỳ chất lỏng nào.
- Không sử dụng các phụ kiện không được nhà sản xuất cho phép. Bảo hành sẽ tự động chấm dứt nếu lỗi máy do các phụ kiện trái phép gây ra.
- Vui lòng kiểm tra xem máy có bị hư hỏng không và xác nhận qua các bộ phận máy được bao gồm sau khi mở gói.
- Để túi nhựa hoặc màng bọc cách xa trẻ sơ sinh và trẻ nhỏ để tránh bị ngạt thở.
- Sử dụng nước máy thành phố làm nguồn nước.
- Xin vui lòng không đổ chất lỏng không rõ nguồn gốc, nước từ nguồn không rõ chất lượng hoặc các chất không liên quan khác. Bất kỳ loại vật liệu nào vào bình chứa nước máy và bình đựng nước lọc.
- Hãy sử dụng máy cẩn thận để tránh bị hư hại do làm rơi máy.
- Đặt máy xa tầm tay trẻ em và vật nuôi.
- Trẻ em và những người không có khả năng vận hành máy một cách an toàn nên sử dụng máy dưới sự giám sát của người giám hộ.
- Đặt máy ở nơi khô ráo, thoáng mát, tránh ánh nắng trực tiếp. Không đặt nó gần bất kỳ nguồn nhiệt nào.
- Không được đặt máy trong môi trường có thể rò rỉ khí dễ cháy.
- Để tránh bị điện giật, không chạm vào phích cắm điện bằng tay ướt.
- Để tránh hư hỏng, không tháo rời hoặc sửa đổi máy hoặc đặt bất kỳ vật nặng nào lên máy.
- Nếu không sử dụng bộ phận phễu trong một thời gian dài, vui lòng đảm bảo rằng nó đã được ngắt kết nối khỏi nguồn điện và đổ hết nước máy và bình đựng nước lọc.
- Nhiệt độ nước đầu vào phải là 5°C -38°C. Nếu nhiệt độ cao hơn 38°C, hộp lọc sẽ bị hỏng và không thể hoạt động. Nếu nhiệt độ thấp hơn 5°C, bộ phận phễu có thể bị đóng băng và các bộ phận của bộ phận phễu sẽ bị hỏng.
- Bộ lấy nước chỉ có thể được lắp đặt và sử dụng trong nhà và với nguồn điện đáng tin cậy nối đất.
- Sử dụng lần đầu hoặc máy lâu ngày không sử dụng, hãy đổ đầy bình nước máy và bỏ hết nước lọc đi. Lắp lại điều này hai lần.
- Luôn sử dụng các bộ phận và phụ kiện đã được chứng nhận để sửa chữa và bảo trì máy máy phân phối.

- Không được sử dụng dung môi hữu cơ như xăng để lau vỏ của bộ phận phối. Nếu cần vệ sinh, vui lòng lau nhẹ bề mặt sản phẩm bằng vải ướt sau đó, bị ngắt khỏi nguồn điện.
- Nếu có bất kỳ điều bất thường nào, hãy rút sản phẩm ra khỏi nguồn điện ngay lập tức và không để bộ phận phối bị lỗi ở chế độ làm việc.
- Khi nâng cấp sản phẩm, một số từ hoặc hình ảnh trong sách hướng dẫn có thể khác với sản phẩm thực tế và sản phẩm thực tế sẽ chi phối trong trường hợp này.
- Nếu người dùng có ý định chiết xuất nước thường hoặc nước 45°C ngay sau khi chiết xuất Nước nóng, lúc đầu có thể có một ít nước nóng chảy ra, nếu có hãy chú ý tránh bị bỏng bởi nước nóng. Nên rút nước xung quanh trong 10 giây để làm mát bộ phận làm nóng.
- Nếu dây nguồn có dấu hiệu bị hỏng, vui lòng ngừng sử dụng sản phẩm. Để tránh rủi ro nguy hiểm, dây nguồn phải được thay thế bởi người được nhà sản xuất ủy quyền.
- Không tự mình tháo rời hoặc sửa chữa bộ phận phối cũng như không giao cho bất kỳ người nào không được phép sửa chữa, vì việc sửa chữa không đúng cách có thể gây nguy hiểm.
- Nhà sản xuất sẽ không chịu trách nhiệm về bất kỳ hậu quả nào do không vận hành thiết bị theo các nguyên tắc trên.

2. Thông số sản phẩm


Tên sản phẩm	Máy lọc nước RO để bàn
Mã sản phẩm	ADD6901HWH01/ADD6901HBK01
Điện áp định mức	220V-240V~
Tổng công suất định mức	2000W-2400W
Công suất gia nhiệt	20L/h, ≥90°C (Max.95°C)
Công suất lọc	2000L
Tốc độ dòng lọc nước	0.13L/phút
Nguồn nước áp dụng	Nước cấp thành phố
Áp lực nước đầu vào	0 - 0.06MPa
Nhiệt độ nước áp dụng	5-38°C

3. Tổng quan về sản phẩm



Lưu ý: Hình ảnh minh họa chỉ mang tính chất tham khảo.

4. Giao diện người dùng





Có thể có độ lệch nhiệt độ $\pm 3^{\circ}\text{C}$ và độ lệch âm lượng $\pm 10\%$, nhiệt độ thực tế và khối lượng phụ thuộc vào môi trường sử dụng và chất lượng nước máy tại địa phương.

5. Lắp đặt


Cài đặt

- Đặt máy trên bề mặt ổn định, mát mẻ, có hệ thống thông gió tốt và cách xa mọi nguồn nhiệt.
- Tháo mép bình nước máy và nhấn bình lên trên; Đổ đầy nước máy vào ngăn đựng nước máy rồi đặt trở lại máy, sau đó đậy nắp lại ngăn đựng nước máy cho đúng cách.
- Cắm dây nguồn vào ổ điện, máy sẽ phát ra âm thanh khi đó bảng hiển thị sẽ sáng lên chứng tỏ máy đang hoạt động.



Lần đầu sử dụng


- Trong lần sử dụng đầu tiên, vui lòng kiểm tra xem có nước rò rỉ hoặc tụ lại không xung quanh máy cấp nước nếu có tiếng động lạ, mùi khét hoặc khói thoát ra khỏi sản phẩm, vui lòng ngắt kết nối dây nguồn và liên hệ với dịch vụ khách hàng.
- Lần sử dụng đầu tiên, để đảm bảo hiệu quả lọc tốt nhất, hãy đổ đầy bể chứa nước máy và đổ bỏ toàn bộ nước đã lọc. Bạn có thể nhấn và giữ "  " + "  " trong 3 giây để làm trống bể và đường ống khi quá trình lọc diễn ra. hoàn thành. Lặp lại điều này cho đến khi hai thùng nước máy được lọc
- Lần đầu tiên sử dụng, để tránh làm nóng khô và bảo vệ máy, vui lòng chiết một ít nước xung quanh trước khi chiết nước nóng.



6. Cách sử dụng cấu trúc


Khóa an toàn

- Chế độ khóa an toàn và ghi nhớ nhiệt độ: Máy sẽ ghi nhớ nhiệt độ nước đã chọn gần nhất, cần mở khóa và nhấn "  " trước khi chiết nước nóng. Máy sẽ tự động khóa nếu không nhấn phím nào trong vòng 10 giây. Nhấn phím khóa an toàn trong 10 giây để tắt khóa an toàn và bộ nhớ nhiệt độ. Máy trở về chế độ "  " sau khi xả nước nếu khóa an toàn bị tắt. Nhấn phím khóa an toàn trong 10 giây để bật lại khóa an toàn và bộ nhớ nhiệt độ




Rửa sạch

- Máy phân phối sẽ tự động súc rửa trước và sau khi lọc nước sau khi được kết nối với nguồn điện và ngăn chứa nước được đầy kín.
- Xả lực mạnh: nhấn và giữ "  " + "  " trong 3 giây và bộ phân phối sẽ rửa sạch trong 1 phút.




Nước lọc

- Nếu bình chứa nước lọc tích hợp ở mức nước thấp, bộ phân phối sẽ tự động bắt đầu lọc nước máy cho đến khi quá trình lọc hoàn tất. Ở trạng thái lọc nước, đèn báo lọc nước luôn sáng, khi bình nước lọc thiếu nước, đèn báo thay nước và lọc nước sẽ nhấp nháy.




Điều chỉnh nhiệt độ nước

- Cài đặt trước nhiệt độ nước: có ba cài đặt trước nhiệt độ nước để lựa chọn - " Ambient " , " 45°C " , " 85°C " và " 95°C " .



Điều chỉnh lượng nước


- Cài đặt trước lượng nước: Có ba cài đặt trước lượng nước để lựa chọn: " 150ml " , " 200ml " , " 300ml " và " 500ml " .



Khai thác nước

- Chọn nhiệt độ và thể tích nước, màn hình hiển thị sẽ hiển thị nhiệt độ nước đã chọn. Sau khi nhấn khóa an toàn (nước xung quanh tự động được mở khóa), nhấn nút chiết nước để chiết ra nước tinh khiết với nhiệt độ và thể tích tương ứng. Bạn có thể nhấn bất kỳ nút nào để dừng trong quá trình trích xuất.

Lưu ý: Khi chiết nước nóng không được đặt tay dưới vòi phun để tránh bị bỏng.




Thay nước

Khi đèn báo "△" nhấp nháy nghĩa là nước trong bình chứa nước máy cần được thay, việc này sẽ xảy ra trong các điều kiện sau:

- Nước trong bình chứa nước máy phải bằng hoặc thấp hơn định mức cho phép
- Chỉ số TDS của nước vòi quá cao


Để thay nước trong ngăn đựng nước máy, bạn mở nắp ngăn đựng nước máy, nhấn ngăn đựng nước máy lên trên và đổ nước xả đi, đổ đầy nước máy vào ngăn chứa nước máy, đặt lại vào máy và đóng nắp lại ngay ngắn

Lưu ý: Không thêm nước vào bình chứa nước vòi khi chưa xả nước thải trong bình chứa ra



Chế độ mùa đông

- Khi nhiệt độ nước máy thấp hơn 10°C, chế độ mùa đông có thể thiết lập.
- Nhấn và giữ nút môi trường xung quanh trong 3 giây, sau đó nhấn nút chiết nước để trích xuất nước đã lọc 25°C. Điều này chỉ có giá trị cho một hoạt động duy nhất.




Chế độ ngủ

- Nếu không có thao tác nào trong vòng 1 phút, bộ phân phối sẽ tự động chuyển sang chế độ ngủ
- Khi bộ phân phối ở chế độ ngủ, chỉ có đèn báo khóa an toàn bật, tất cả các đèn báo khác đều tắt
- Chạm vào nút bất kỳ để kết thúc chế độ ngủ.

Làm sạch bể và đường ống

- Nhấn và giữ nút "45°C" và nút "300ml" trong 3 giây, bộ phân phối sẽ chiết nước cho đến khi bình đựng nước lọc và các đường ống bên trong trống.

Lưu ý: Để tránh làm nóng khô, sau khi xả bằng một phím, vui lòng chiết một ít nước xung quanh trước khi chiết nước nóng



7. Bảo trì định kỳ


Nếu sản phẩm không được sử dụng trong hơn hai ngày, bạn nên thay nước trong ngăn đựng nước máy, sau đó đổ sạch ngăn chứa và đường ống hai lần.

Nếu bộ phân phối không được sử dụng trong hơn một tuần, vui lòng đổ hết nước trong đó và ngắt kết nối bộ phân phối khỏi nguồn điện. Niêm phong hộp lọc và bảo quản trong tủ lạnh (2-5°C, không cho vào ngăn đá). Khi bạn sử dụng lại, vui lòng làm theo quy trình vệ sinh cho lần sử dụng đầu tiên.

tẩy cặn bể nước máy

- Nên tẩy cặn bể chứa nước máy 3 tháng một lần để tránh đóng cặn nghiêm trọng trong bể nước máy.
- Quy trình tẩy cặn: đổ đầy nửa bình nước máy và thêm 30g axit xitric. Khuấy nhẹ rồi ngâm trong 2 giờ (không đặt bình chứa nước máy trở lại bộ phận phân phối). Sau đó loại bỏ dung dịch axit xitric và làm sạch toàn bộ bể chứa nước bằng nước máy.

* Vui lòng mua riêng bàn chải làm sạch và axit xitric.



8. Thay thế bộ lọc

Vui lòng thay hộp mực lọc theo chỉ báo tuổi thọ của bộ lọc trên bảng hiển thị, hoặc chu kỳ thay thế được đề xuất. Hộp lọc mới có thể được mua từ ủy quyền các nhà bán lẻ và các trung tâm dịch vụ. Mô hình là ADD541.


Tên sản phẩm	Lõi lọc RO
Mã sản phẩm	ADD541
Chu kỳ thay thế được đề xuất	Máy sẽ tự động phát hiện 1 năm hoặc 2000L nước theo đúng chỉ định nhà máy
* Chỉ có thể sử dụng hộp lọc Philips chính hãng.	

Filter lifetime indicator

- Màu sắc của đèn báo tuổi thọ bộ lọc hiển thị tuổi thọ còn lại của hộp lọc:
 - Đèn xanh: còn lại hơn 10% tuổi thọ;
 - Đèn đỏ nhấp nháy: tuổi thọ còn lại dưới 10%;
 - Đèn đỏ liên tục: tuổi thọ còn ít hơn 7 ngày và vui lòng thay bộ lọc ngay lập tức.


Hướng dẫn thay thế hộp lọc

- Tắt nguồn
- Lấy bình nước máy ra rồi đến nắp trên của máy;
- Xoay lõi lọc theo chiều ngược kim đồng hồ "↺" để mở khóa và lấy lõi ra
- Lắp hộp lọc mới vào bộ phân phối. Xoay nó theo chiều kim đồng hồ "↻" và đẩy nắp trên của máy; đưa thùng chứa nước thô trở lại máy phân phối
- Đặt lại tuổi thọ của hộp lọc và làm theo quy trình vệ sinh trong lần sử dụng đầu tiên.



Đặt lại tuổi thọ của bộ lọc

- Nhấn và giữ "Ambient" + "150ml" trong 3 giây (3 âm thanh nhắc nhở) để đặt lại tuổi thọ của hộp lọc. Sẽ có 3 tiếng bip. Đèn báo tuổi thọ chuyển sang màu xanh lam, và điều này có nghĩa là tuổi thọ của bộ lọc đã được đặt lại thành công.



9. Mã lỗi

E1: Cảm biến nhiệt độ nước máy bất thường

Giải pháp: Kiểm tra bình chứa nước máy, loại bỏ nước nếu nhiệt độ nước vượt quá 55°C; đặt bình chứa nước máy trở lại máy. Vui lòng liên hệ với dịch vụ khách hàng nếu vấn đề không thể giải quyết được.

E2: Cảm biến nhiệt độ nước đầu ra bất thường

Giải pháp: Chiết 300ml nước thường. Vui lòng liên hệ với bộ phận dịch vụ khách hàng nếu vấn đề không thể giải quyết được.

E4: Nhiệt độ phần tử gia nhiệt cảm biến bất thường

Giải pháp: Ngừng sử dụng bộ phận phối hoặc chiết 300ml nước xung quanh, để hệ thống sưởi phần tử để làm nguội đến nhiệt độ bình thường và sau đó chiết ra nước nóng. Vui lòng liên hệ với bộ phận dịch vụ khách hàng nếu vấn đề không thể giải quyết được.

E6: Báo động khi chuẩn bị nước bất thường

Giải pháp: Tắt nguồn trong 1-2 phút, kiểm tra xem hộp lọc đã được lắp đúng chưa, sau đó cắm lại nguồn. Vui lòng liên hệ với bộ phận dịch vụ khách hàng nếu vấn đề không thể giải quyết được.

EU: Sự cố bảng hiển thị

Giải pháp: Vui lòng liên hệ với bộ phận dịch vụ khách hàng.

10. Xử lý sự cố

Lỗi	Nguyên nhân	Giải pháp
Không thể lấy nước thường	Sản phẩm chưa được kết nối với nguồn điện	Kiểm tra xem máy có thể kết nối tốt với nguồn không
	Nút không được nhấn đúng cách	Nhấn nút vắt nước lần nữa
Không thể lấy nước nóng	Bộ phận phối được làm nóng khô	Trích xuất nước xung quanh nhiều lần, và sau đó rút nước nóng
	Nước trong bình lọc nước ở mức thấp	Đợi một lúc cho đến khi đèn báo lọc nước ngừng nhấp nháy
Không thể lọc nước	Hộp lọc chưa được cài đặt đúng cách	Ngắt kết nối bộ phận phối khỏi nguồn điện. Mở nắp trên của máy và lấy bộ lọc ra hộp mực, sau đó cài đặt nó đúng cách
	Nước trong bể nước máy là ở mức nước thấp	Lấy bình nước máy ra và thay nước
	Bình chứa nước máy không được lắp đặt đúng cách	Kiểm tra bình chứa nước máy và lắp đặt đúng cách
Tiếng ồn lạ khi lọc	Chất lượng nước máy không đáp ứng được yêu cầu và hộp mực lọc bị chặn trước đó hơn cả mong đợi	Thay hộp mực lọc và kiểm tra lại
Rò rỉ nước	Khay nhỏ giọt có thể tháo rời đã đầy	Đổ hết nước trong khay chứa
	Van kiểm tra trên nước máy bề bồn bị chặn hoặc đặt sai vị trí	Đặt van một chiều trở lại vị trí ban đầu hoặc liên hệ với bộ phận dịch vụ khách hàng để thay đổi
	Van bịt kín ở phía dưới bình nước máy bị tắc	loại bỏ sự tắc nghẽn
	Nước rỉ ra từ bộ phận phối	Đổ hết nước máy và bình đựng nước lọc, tắt nguồn, sau đó liên hệ với bộ phận dịch vụ khách hàng
Nước có mùi hôi	Máy lọc không được vệ sinh kĩ	Tuân thủ theo quy định súc rửa trong lần đầu sử dụng
	Máy lọc nước không được sử dụng trong thời gian dài	Tuân thủ theo quy định súc rửa trong lần đầu sử dụng
	Hộp lọc không được thay đổi vì yêu cầu	Thay đổi hộp mực lọc

Rò rỉ điện	Tiếp đất kém	Phải sử dụng phích cắm ba lõi có nối đất đáng tin cậy
	Dây nguồn bị hỏng	Vui lòng liên hệ với dịch vụ khách hàng
Nút/bảng hiển thị không phản hồi	Những phần hư hại	Vui lòng liên hệ với dịch vụ khách hàng
	Hệ thống dừng lại	Ngắt kết nối bộ phân phối khỏi nguồn điện 1-2 phút sau đó gắn lại

11. Danh sách đóng gói

Máy lọc nước	1x
Khay đựng ly nước	1x
Hướng dẫn sử dụng	1x
Hướng dẫn sử dụng và biện pháp phòng ngừa	1x

12. Bảo hành và dịch vụ

Nếu bạn cần thông tin hoặc có bất kỳ câu hỏi nào, vui lòng truy cập www.philips.com/support hoặc liên hệ với trung tâm dịch vụ khách hàng tại quốc gia/khu vực của bạn. Nếu không có trung tâm dịch vụ tiêu dùng ở quốc gia/khu vực của bạn, vui lòng liên hệ với nhà phân phối địa phương của bạn. Trong vòng hai năm kể từ ngày mua, bạn sẽ nhận được dịch vụ bảo hành miễn phí đối với mọi hư hỏng do sự cố trong quá trình sản xuất hoặc bất kỳ hư hỏng nào đối với các bộ phận trong điều kiện sử dụng bình thường được nhân viên dịch vụ bảo trì của chúng tôi xác nhận. Dịch vụ bảo hành không bao gồm các vật tư tiêu hao được thay thế thường xuyên, thiết bị phụ trợ, chi phí vận chuyển và dịch vụ giao hàng tận nơi. Vui lòng xuất trình bằng chứng mua hàng cho nhân viên dịch vụ khi bảo trì.

Vui lòng giữ lại hướng dẫn sử dụng này để tham khảo sau này.



Register your product and learn more via the website link below:

www.philips.com/water

Specifications are subject to change without notice

© 2024 AquaShield

All rights reserved.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Hong Kong AquaShield Health Technology Company Limited and Hong Kong AquaShield Health Technology Company Limited is the warrantor in relation to this product.

Rev A MAR 24

