

Product Guide
Important safety and health information

製品ガイド
安全な取り扱いに関する情報

产品指南
重要的安全和健康信息

제품 가이드
중요 안전 및 건강 정보

產品指南
重要的安全與健康資訊

उत्पाद मार्गदर्शिका
महत्वपूर्ण सुरक्षा और स्वास्थ्य जानकारी

คู่มือผลิตภัณฑ์
ข้อมูลด้านความปลอดภัยและสุขภาพที่สำคัญ

 Microsoft

Product Guide

⚠ This symbol identifies safety and health messages in this Device Guide

⚠ WARNING : Read Safety & Health Info

Read this guide for important safety and health information and the terms of the Limited Warranty that apply to the Microsoft® device that you have purchased. Keep all printed guides for future reference. Failure to follow instructions and properly set up, use, and care for this product can increase the risk of serious injury or death, or damage to the device or devices. For an online version of this guide and additional support, safety and health information on the following topics (Photosensitive Seizures, Hearing Safety and Healthy Computing) go to: www.microsoft.com/support

⚠ Warning: Do Not Attempt Repairs

Do not attempt to take apart, open, service, or modify the product, accessories, or power supply. Doing so could present the risk of electric shock or other hazard. Any evidence of any attempt to open and/or modify this device, including any peeling, puncturing, or removal of any of the labels, will void the Limited Warranty. Heed all warnings and follow all instructions.

⚠ Warning: Choking Hazard

This device may contain small parts which may be a choking hazard to children under 3. Keep small parts away from children.

⚠ Warning: Small Children

This device and its accessories are not toys. Do not allow small children to play with them because they could hurt themselves or others, damage the device, or use services that increase your mobile device bill. Keep the device and all its parts and accessories out of the reach of small children.

⚠ Warning: Battery-Powered Devices

These precautions apply to all products that use user replaceable rechargeable or disposable batteries. Improper use of batteries may result in battery fluid leakage, overheating, or explosion. Released battery fluid is corrosive and may be toxic. It can cause skin and eye burns, and is harmful if swallowed.

To reduce the risk of injury:

- Keep batteries out of reach of children.
- Do not heat, open, puncture, mutilate, or dispose of batteries in fire.
- Do not mix new and old batteries or batteries of different types (for example, carbon-zinc and alkaline batteries).
- Do not allow metal objects to touch the battery terminals on the device; they can become hot and cause burns.
- Remove the batteries if they are worn out or before storing your device for an extended period of time. Always remove old, weak, or worn-out batteries promptly and recycle or dispose of them in accordance with Local and National Disposal Regulations.
- If a battery leaks, remove all batteries, taking care to keep the leaked fluid from touching your skin or clothes. If fluid from the battery comes into contact with skin or clothes, flush skin with water immediately. Before inserting new batteries, thoroughly clean the battery compartment with a damp paper towel, or follow the battery manufacturer's recommendations for cleanup.

Disposable (non-rechargeable) batteries only:

- **Caution** Risk of explosion if battery is replaced by an incorrect type. Use and replace only with correct size and type (alkaline, zinc-carbon, or zinc-chloride) of batteries.

⚠ Warning: Battery Safety

Products which contain a built-in non-user replaceable battery; Improper use may result in explosion. Do not heat, open, puncture, mutilate, or dispose of the product in fire. Do not leave the device in direct sunlight for an extended period of time, which could cause melting or battery damage. If the battery in this device is not intended to be user replaceable, it should only be replaced by Microsoft or a Microsoft Authorized Service Provider. See www.microsoft.com/support for additional details.

⚠ Warning: Use Near Water

To reduce the risk of fire or shock, do not use this device near water and do not expose it to rain or moisture. Do not attempt to dry device with a hair dryer or a microwave oven.

⚠ Warning: Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often, but not always, posted and can include fueling areas, such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders. When you are in such an area, turn off your mobile device, and do not remove or install battery chargers, AC adapters, or any other accessory. In such areas, sparks can occur and cause an explosion or fire.

⚠ Warning: AC Adapter Safety

Failure to take the following precautions can result in serious injury or death from electric shock or fire or in damage to the device. To select an appropriate power source for your device:

- Use only the power supply unit and AC power cord that came with your device or that you received from an authorized Microsoft retailer.
- Do not use non-standard power sources, such as generators or inverters, even if the voltage and frequency appear acceptable. Only use AC power provided by a standard wall outlet.
- Do not overload your wall outlet, extension cord, power strip, or other electrical receptacle. Confirm that they are rated to handle the total current (in amps [A]) drawn by the device (indicated on the power supply unit) and any other devices that are on the same circuit.
- On devices where the AC prongs may be folded for storage, before plugging the AC adapter into a power outlet, make sure its prongs are fully extended.
- On devices where the AC prongs are removable and where the power supply uses a universal adapter, before plugging the AC adapter into a power outlet, make sure the prong assembly is of the proper configuration for the power outlet and fully seated into the adapter.

⚠ Warning: Headset Devices

Extended exposure to high volumes when using a headset may result in temporary or permanent hearing loss. To prevent damage to your headset, avoid sitting or stepping on the headset, its cable, or the cable connector.

Headset devices may attract dangerous objects like staples and paper clips. Take care to avoid harm that may occur from the retention of dangerous objects on the headset.

⚠ Warning: Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so. In an aircraft, turn off your device whenever instructed to do so by airline staff, or prior to packing a wireless device in luggage. Please consult airline staff about using it in flight.

⚠ Caution: Avoid Skin Irritation

This device is made of materials commonly used in worn consumer electronic devices. However, certain people may develop irritation due to allergies or sensitivities. To reduce the risk of skin irritation:

- Wipe the device dry with a cloth if it gets wet.
- Avoid using lotions or other products under the device.
- Do not wear over injured skin.
- Tighten until snug, but not uncomfortably tight.

If your skin becomes irritated, stop using the device. If symptoms are severe or persist, consult your doctor.

⚠ Caution: Cable and cord safety

Arrange all cables and cords so that people and pets are not likely to trip over or accidentally pull on them as they move around or walk through the area. Do not allow children to play with cables and cords.

To avoid damaging the power cords and power supply:

- Protect the power cords from being walked on.
- Protect cords from being pinched or sharply bent, particularly where they connect to the power outlet, the power supply unit, and the device.
- Do not jerk, knot, sharply bend, or otherwise abuse the power cords.
- Do not expose the power cords to sources of heat.
- Keep children and pets away from the power cords. Do not allow them to bite or chew on them.
- When disconnecting the power cords, pull on the plug—do not pull on the cord.

- If a power cord or power supply becomes damaged in any way, stop using it immediately.
- Unplug your device during lightning storms or when unused for long periods of time.
- For devices with an AC power cord that connects to the power supply, always connect the power cord according to the following instructions:

1 Plug the AC power cord into the power supply until it seats fully.

2 Plug the other end of the AC power cord into the wall outlet.

⚠ Caution: Parts of this device are magnetic

It may attract metallic materials. To reduce the potential risk of sparks, verify the electrical connection area is free of metallic objects before interconnecting devices. In order to reduce the likelihood of magnetic fields interfering with compass readings, disrupting the proper operation of pacemakers, or corrupting magnetically stored data, do not place credit cards or other magnetic storage media or magnetically sensitive devices near this device.

⚠ Caution: Do not swing or carry your device by Touch Cover or Type Cover

The keyboard and (host device) are held together only by magnets and can detach, leading to potential product damage or injury to nearby people or objects.

⚠ Caution: Personal Medical Devices

Radio-frequency emissions from electronic equipment can negatively affect the operation of other electronic equipment, causing them to malfunction. Although the device is designed, tested, and manufactured to comply with regulations governing radio frequency emission in countries such as the United States, Canada, the European Union, and Japan, the wireless transmitters and electrical circuits in the device may cause interference in other electronic equipment. Therefore, please take the following precautions:

⚠ Persons with pacemakers:

- The Health Industry Manufacturers Association recommends that a minimum separation of 15 cm (6 inches) be maintained between a wireless device and a pacemaker to avoid potential interference with the pacemaker.
- Should not carry the device in the breast pocket.
- If you have any reason to suspect that interference is taking place, turn the device off immediately.

⚠ Other Medical Devices:

If you use any other personal medical device, consult the medical device manufacturer or your physician to determine if it is appropriate for you to use other electronic devices near your medical device.

⚠ Caution: Health Warning

Use of electronic input devices may be linked to serious injuries or disorders. When using a computer, as with many activities, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. However, if you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, **DO NOT IGNORE THESE WARNING SIGNS. PROMPTLY SEE A QUALIFIED HEALTH PROFESSIONAL**, even if symptoms occur when you are not working at your computer. Symptoms like these can be associated with painful and sometimes permanently disabling injuries or disorders of the nerves, muscles, tendons, or other parts of the body. These musculoskeletal disorders (MSDs) include carpal tunnel syndrome, tendonitis, tenosynovitis, and other conditions. While researchers are not yet able to answer many questions about MSDs, there is general agreement that many factors may be linked to their occurrence, including: overall health, stress and how one copes with it, medical and physical conditions, and how a person positions and uses his or her body during work and other activities (including use of a keyboard or mouse). The amount of time a person performs an activity may also be a factor. Some guidelines that may help you work more comfortably with your computer and possibly reduce your risk of experiencing an MSD can be found in the "Healthy Computing Guide" available at www.microsoft.com/support

⚠ Caution: Heat Related Concerns

The device may become very warm during normal use. The device complies with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950-1). To reduce heat related concerns, follow these guidelines:

- Set up your device on a stable work surface that allows for adequate air circulation under and around the device.
- Use caution when operating your device on a pillow, blanket, or other soft material, because the material can block the airflow which may result in the device overheating.

- If your device is on your lap and gets uncomfortably warm, remove it from your lap and place it on a stable work surface.

Usage and Cleaning

Use in accordance with these instructions:

- Do not use near any heat sources.
- Only use attachments/accessories specified by Microsoft.
- Clean only with dry cloth.
- Do not allow this product to become wet. To reduce the risk of fire or shock, do not expose this product to rain or other types of moisture.

Laser and LED Specifications


Caution Use of controls or adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Laser Devices

This device complies with International Standard IEC 60825-1:2007-03 for a Class 1 laser product.

This device also complies with 21 CFR 1040.10 and

1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.



Optical (LED) Mouse

This product has been evaluated to comply with International Standard IEC 62471 (2006-07).

Regulatory Information

Not intended for use in machinery, medical or industrial applications. Any changes or modifications not expressly approved by Microsoft could void the user's authority to operate this device. This product is for use with NRTL Listed (UL, CSA, ETL, etc.), and/or IEC/EN 60950-1 compliant (CE marked) Information Technology equipment. No serviceable parts included. This device is rated as a commercial product for operation at +41°F (+5°C) to +95°F (+35°C).

This Class B digital apparatus complies with, as applicable, Part 15 of the U.S. Federal Communications Commission (FCC) rules, Canadian ICES-003, RSS-Gen, RSS-210 and RSS-310. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Statement of Compliance with EU Directives


Hereby, Microsoft Corporation declares that this product is in compliance with the essential requirements and other relevant provisions of Directives, 2006/95/EC, 2004/108/EC, 2011/65/EU, and 1999/5/EC, as applicable. The technical documentation as required by the Conformity Assessment procedure is kept at the following address:

Company: Microsoft Ireland Operations Limited
Address: One Microsoft Place
South County Business Park
Dublin D18 P521
Ireland
Country: Ireland
Telephone number: +353 1 295 3826
Fax number: +353 1 706 4110
Internet: aka.ms/eucompliance doc



Complies with
IMDA Standards
DA107473


Disposal of Waste Batteries and Electrical & Electronic Equipment

 This symbol on the product or its batteries or its packaging means that this product and any batteries it contains must not be disposed of with your household waste. Instead, it is your responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. For more information about where to drop off your batteries and electrical and electronic waste, please contact your local city/municipality office, your household waste disposal service, or the shop where you purchased this product. Contact eRecycle@microsoft.com for additional information about waste from electrical and electronic equipment and waste batteries.

This product may use lithium or alkaline batteries.

Information and views expressed in this document, including URL and other Internet Web site references, may change without notice. This document does not provide you with any legal rights to any intellectual property in any Microsoft product. You may copy and use this document for your internal, reference purposes.

①



Remove the battery cover and insert battery.

拆卸電池蓋并插入電池。


배터리 커버를 열고 배터리를 삽입합니다.

取下電池蓋並裝入電池。

เปิดฝาช่องใส่แบตเตอรี่และใส่แบตเตอรี่ลงไป

बैटरी का कवर निकालें और बैटरी डालें।

②



Insert the transceiver into a USB port on your computer.

將收发器插入计算机的USB端口。


컴퓨터의 USB 포트에 송수신기를 삽입하십시오.

將接收器插入電腦的USB連接埠。

เสียบตัวรับส่งสัญญาณเข้ากับพอร์ต USB ในคอมพิวเตอร์ของคุณ

ट्रांससीवर को को अपने कंप्यूटर पर एक यूएसबी पोर्ट में डालें।

i1



Power On/Off.

开启/关闭电源。


전원 켜기/끄기.

電源開啟/關閉。

เปิดและปิดเครื่อง

पावर चालू / बंद।

i2



Transceiver storage compartment at the bottom of mouse.

收发器存储槽位于鼠标底部。

마우스 아래쪽의 송/수신기 보관 공간.

接收器存放槽位於滑鼠底部。

ช่องที่จัดเก็บตัวรับส่งสัญญาณใต้เมาส์

माउस के निचले भाग में स्थिति ट्रांससीवर स्टोरेज कंपार्टमेंट।